

SAMPLE MODEL NUMBER

Y 2 3 A N 2 4 B 1 A A C A B A

TABLE OF CONTENTS

Cabinet Components.....	Page 2
Supply Air Components.....	Page 2
Electrical Components including compressors and condenser fan motors	Page 3
Refrigerant Components	Page 25
Indoor Blower including motors	Page 27
Exhaust Air	Page 39
Heat Components.....	Page 48
Filter Options	Page 56
Disconnect Options	Page 56
Convenience Outlet Options.....	Page 56

This replacement parts list is based on first production units only. It is not intended to be a comprehensive parts list.

Part numbers indicated by bold numerals represent new parts.

CABINET COMPONENTS

Description	Part Number	Model		
		Y22	Y23	Y24
Bracket, Door Latch	S1-073-19224-000	12	12	12
Bracket, Latch	S1-073-19226-000	12	12	12
Bracket, Support Motor	S1-026-25556-000	4	-	-
Clamp, Motor	S1-026-25568-000	-	3	4
Channel, Upright	S1-373-16066-045	1	1	1
Channel, Upright	S1-373-16066-047	3	3	3
Channel, Upright	S1-373-16066-049	2	2	2
Channel, Upright	S1-073-18639-000	1	1	1
Channel, Upright	S1-073-15240-000	2	2	2
Channel, Ext. Upright	S1-073-26009-000	1	1	1
Channel, Roof Joint	S1-373-16066-076	5	5	5
Fan, Prop., 24" Dia., CW, 3 Bl., 25 Deg., 1/2" Bore	S1-026-25511-000	4	-	-
Fan, Prop., 24" Dia., 4 Bl., 38 Deg.	S1-026-35534-000	-	3	4
Frame, Perimeter Cond	S1-073-15249-000	1	1	1
Frame, Perimeter Cond	S1-073-15248-000	1	1	1
Frame, Filter Bag, Slide	S1-029-22123-000	3	3	3
Frame, Perimeter End	S1-073-20171-000	1	1	1
Frame, Perimeter End P.E.	S1-073-16140-000	1	1	1
Frame, Perimeter P.E.	S1-073-16139-000	1	1	1
Frame, Perimeter P.E.	S1-073-16138-000	1	1	1
Guard, Coil, Wireform	S1-026-34582-000	10	10	10
Guard, Fan	S1-026-34562-000	4	3	4
Hinge, Door 4"	S1-029-22174-000	12	12	12
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	12	12	12
Mount, Motor	S1-026-34581-000	-	3	4
Panel, Coil Side (V-condenser Pnl)	S1-073-15239-000	-	5	6
Panel, V-condenser Coil	S1-073-21739-000	3	-	-
Panel, Fan Deck	S1-073-15242-000	-	1	-
Panel, Fan Deck	S1-073-15243-000	2	1	2
Panel, Roof	S1-073-15906-000	4	4	4
Panel, Roof	S1-073-15907-000	1	1	1
Panel, Roof Heat Section	S1-073-15905-000	1	1	1
Plate, Door Latch	S1-073-19225-000	12	12	12
Post, Corner Cond	S1-073-15234-000	2	2	2
Post, Corner P.E.	S1-373-16066-053	1	1	1
Post, Corner P.E.	S1-373-16066-051	1	1	1
Panel, Door	S1-373-16066-070	6	6	6
Tongue, Door Latch Slide	S1-029-22121-000	12	12	12
Gasket, Strip 1/2" X 10.0" (Order By Ft.)	S1-028-12049-000	-	-	-
Rainshield, 8.75" X 1.0" Bore	S1-062-30549-000	4	-	-

SUPPLY AIR COMPONENTS

BOTTOM SUPPLY

POSITION 4=A OR D

POSITION 5 & 6 = N2, N4, S2, S4, E4, E8, OR E1

Panel, Rear	S1-373-18607-006	1	1	1
-------------	------------------	---	---	---

POSITION 4= A OR D
POSITION 5 & 6 = N7, OR S7 (40 TON ONLY)

Description	Part Number	Model		
		Y22	Y23	Y24
Panel, Blockoff, Side	S1-073-15224-000	-	-	1

POSITION 4 = A OR D
POSITION 5 & 6 = C0

Panel, Door	S1-373-16066-070	1	1	1
-------------	------------------	---	---	---

POSITION 4 = A OR D
POSITION 5 & 6 = W1, W2, OR X1

Panel, Door	S1-373-16066-070	1	1	1
Tongue, Door Latch Slide	S1-029-22121-000	1	1	1
Knob, Door, 1" Exposed Thread	S1-029-22122-000	1	1	1

REAR SUPPLY

POSITION 4 = B OR E
POSITION 5 & 6 = N2, N4, S2, OR S4

Panel, Blockoff, Side	S1-073-15224-000	1	1	1
-----------------------	-------------------------	---	---	---

POSITION 4 = B OR E
POSITION 5 & 6 = N2, N4, S2, OR S4

Panel, Blockoff, Side	S1-073-15224-000	1	1	1
-----------------------	-------------------------	---	---	---

POSITION 4 = B OR E
POSITION 5 & 6 = N7, OR S7 (40 TON ONLY)

Panel, Blockoff, Side	S1-073-15224-000	1	1	1
-----------------------	-------------------------	---	---	---

POSITION 4 = B OR E
POSITION 5 & 6 = C0

Panel, Door	S1-373-16198-070	1	1	1
Tongue, Door Latch, Slide	S1-029-22121-000	1	1	1
Knob, Door, 1" Exposed Thread	S1-029-22122-000	1	1	1
Panel, Blockoff, Side	S1-073-15224-000	1	1	1

FRONT SUPPLY

POSITION 4 = C OR F
POSITION 5 & 6 = N2, N4, N7, E1, E4, E8, C0, W1, W2, X1, X2

Panel, Rear	S1-373-18607-006	1	1	1
Panel, Blockoff, Side	S1-073-15224-000	-	-	-

ELECTRICAL COMPONENTS INCLUDING COMPRESSORS AND CONDENSER FAN MOTORS
208/230-3-60 VOLTAGE CODE 2 = NOMENCLATURE 7TH POSITION

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8
POSITION 7 = 2
POSITION 8 = M, N, O, Q, R
POSITION 14 = H, I, J

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M36WC	S1-015-03151-004	2	-	-
Compressor, ZR12M3TWC	S1-015-02917-004	-	3	4

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 2

POSITION 8 = M, N, O, Q, R

POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 50 Amp., 24V	S1-024-25846-000	-	3	4
Contact, Elec., 3 Pole, 60 Amp.	S1-024-25848-000	2	-	-
Control, Pressure, Spno	S1-024-27557-000	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	2	2	2
Fuse, Dual, 20 Amp., 250V, 9 x 16 x 2	S1-025-05750-000	-	3	-
Fuse, Dual, 25 Amp., 250V, .56x	S1-025-26338-000	2	-	-
Fuse, Dual, 30 Amp., 250V, 9 x 16 x 2	S1-025-04649-000	-	-	3
Fuse, Dual, 60 Amp., 250V, 13 x 16 x 3	S1-025-13292-000	-	9	12
Fuse, Dual, 70 Amp., 250V, 3/4x	S1-025-18539-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max. 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #5, 100 Amp., 250V, 3 Pole	S1-025-26395-000	2	-	-
Fuseholder, #19, 30 Amp., 250V, 3 Pole	S1-025-18281-000	-	1	1
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	1	3	4
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 1 1/4HP, 208/230V	S1-024-32068-001	-	3	4
Motor, Fan, 3/4HP, 208/230V	S1-024-19879-000	4	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	2	2	2
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Terminal Block, 1 Pole	S1-025-32615-000	-	2	-
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	1	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	1	-	-
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	1	1	1
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 208/230V	S1-025-37431-001	1	1	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 2

POSITION 8 = A, C

POSITION 14 = D, E, F

Description	Part Number	Model		
		Y22	Y23	Y24
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	-	-	1
Compressor, ZR12M3TWC	S1-015-02917-004	-	-	4
Contact, Elec., 3 Pole	S1-024-26051-000	-	-	4
Contact, Elec., 3 Pole, 50 Amp., 24V	S1-024-25846-000	-	-	4
Control, Pressure, Spno	S1-024-27557-000	-	-	1
Controller, Synthesis	S1-031-01918-000	-	-	1
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	-	-	2
Fuse, Dual, 30 Amp., 250V, 9 x 16 x 2	S1-025-04649-000	-	-	3
Fuse, Dual, 60 Amp., 250V, 13 x 16 x 3	S1-025-13292-000	-	-	12
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	-	2
Fuseholder, #19, 30 Amp., 250V, 3 Pole	S1-025-18281-000	-	-	1
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	-	-	4
Hinge, 4"	S1-029-22171-000	-	-	2
Latch, Door Safety	S1-029-21185-000	-	-	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	-	-	1
Motor, Fan, 1 1/4HP, 208/230V	S1-024-32068-001	-	-	4
Pressure, Tap	S1-023-16881-000	-	-	1
Resistor, 1K Ohm	S1-031-01914-000	-	-	1
Sensor, Discharge Air Temperature	S1-031-01915-000	-	-	1
Sensor, Return Air Temperature	S1-031-01917-000	-	-	1
Terminal Block, 1 Pole	S1-025-32615-000	-	-	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	-	-	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	-	-	1
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	-	-	1
Transformer, 208/230V	S1-025-37431-001	-	-	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 2

POSITION 8 = M, N, O, Q, R

POSITION 14 = D, E, F

Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	-	-	1
Compressor, ZR12M3TWC	S1-015-02917-004	-	-	4
Contact, Elec., 3 Pole	S1-024-26051-000	-	-	4
Contact, Elec., 3 Pole, 50 Amp., 24V	S1-024-25846-000	-	-	4
Control, Pressure, Spno	S1-024-27557-000	-	-	1
Controller, Motor, 1HP, 208/230V	S1-024-32028-004	-	-	1
Controller, Synthesis	S1-031-01919-000	-	-	1
Transducer, Duct Pressure	S1-031-01209-700	-	-	1
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	-	-	2
Fuse, Dual, 30 Amp., 250V, 9 x 16 x 2	S1-025-04649-000	-	-	3
Fuse, Dual, 60 Amp., 250V, 13 x 16 x 3	S1-025-13292-000	-	-	12
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	-	2

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 2

POSITION 8 = M, N, O, Q, R

POSITION 14 = D, E, F (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Fuseholder, #19, 30 Amp., 250V, 3 Pole	S1-025-18281-000	-	-	1
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	-	-	4
Hinge, 4"	S1-029-22171-000	-	-	2
Latch, Door Safety	S1-029-21185-000	-	-	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	-	-	1
Motor, Fan, 1 1/4HP, 208/230V	S1-024-32068-001	-	-	4
Pressure, Tap	S1-023-16881-000	-	-	1
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	-	-	2
Resistor, 1K Ohm	S1-031-01914-000	-	-	1
Sensor, Discharge Air Temperature	S1-031-01915-000	-	-	1
Sensor, Outdoor Temperature	S1-031-01916-000	-	-	1
Sensor, Return Air Temperature	S1-031-01917-000	-	-	1
Switch, Lockout, O Def F	S1-025-32743-000	-	-	1
Terminal Block, 1 Pole	S1-025-32615-000	-	-	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	-	-	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	-	-	1
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	-	-	1
Transducer, Pressure	S1-025-37463-000	-	-	2
Transformer, 208/230V	S1-025-37431-001	-	-	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 2

POSITION 8 = A, C

POSITION 14 = H, I, J

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M36WC	S1-015-03151-004	2	-	-
Compressor, ZR12M3TWC	S1-015-02917-004	-	3	4
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 50 Amp., 24V	S1-024-25846-000	-	3	4
Contact, Elec., 3 Pole, 60 Amp.	S1-024-25848-000	2	-	-
Control, Pressure, Spno	S1-024-27557-000	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	2	2	2
Fuse, Dual, 20 Amp., 250V, 9 x 16 x 2	S1-025-05750-000	-	3	-
Fuse, Dual, 25 Amp., 250V, .56X	S1-025-26338-000	2	-	-
Fuse, Dual, 30 Amp., 250V, 9 x 16 x 2	S1-025-04649-000	-	-	3
Fuse, Dual, 60 Amp., 250V, 13 x 16 x 3	S1-025-13292-000	-	9	12
Fuse, Dual, 70 Amp., 250V, 3/4X	S1-025-18539-000	6	-	-

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 2

POSITION 8 = A, C

POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #5, 100 Amp., 250V, 3 Pole	S1-025-26395-000	2	-	-
Fuseholder, #19, 30 Amp., 250V, 3 Pole	S1-025-18281-000	-	1	1
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	1	3	4
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 1 1/4HP, 208/230V	S1-024-32068-001	-	3	4
Motor, Fan, 3/4HP, 208/230V	S1-024-19879-000	4	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	1	1
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	1	1	1
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 208/230V	S1-025-37431-001	1	1	1

460-3-60 VOLTAGE CODE 4 = NOMENCLATURE 7TH POSITION

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 4

POSITION 8 = M, N, O, P, Q, R

POSITION 14 = H, I, J

POSITION 10 = C HPC

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	3	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	6	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole	S1-024-26051-000	1	-	-
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 4

POSITION 8 = M, N, O, P, Q, R

POSITION 14 = H, I, J

POSITION 10 = C HPC (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Controller, 2HP, 3.6 Amp., 460V	S1-024-32028-007	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	3	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #23, 30 Amp., 600V, 1 Pole	S1-025-35307-000	1	-	-
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 3/4HP, 208-230/460V, 3 Pole	S1-024-31439-000	1	-	-
Motor, Fan, 1 1/4HP, 460/380/415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	3	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Fan, Prop., 3 Bl., 24" Dia., 25 Deg., 5/8" Bore	S1-026-35581-000	1	-	-
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	2	2	2
Relay, Time Delay, 30 Sec	S1-024-32079-000	2	-	-
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Switch, Lockout, O Def F	S1-025-32743-000	1	1	1
Terminal Block, 1 Pole	S1-025-32615-000	2	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	-	2	-
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	-	-
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	2	2	2
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	1	1
Transducer, Pressure	S1-025-37463-000	2	2	2
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 1 = ALL EXCEPT F
POSITION 5 & 6 = ALL EXCEPT E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = G
POSITION 10 = C HPC

Description	Part Number	Model		
		Y22	Y23	Y24
Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	3	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR16M2TWE	S1-015-03153-004	-	2	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	-	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	6	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole	S1-024-26051-000	1	-	-
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	3	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #23, 30 Amp., 600V, 1 Pole	S1-025-35307-000	1	-	-
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 3/4HP, 575V	S1-024-31408-000	-	4	-
Motor, Fan, 1 1/4HP, 460/380/415V, 3 Pole	S1-024-32068-002	-	-	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	3	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	2	2	2
Relay, Time Delay, 30 Sec	S1-024-32079-000	2	-	-
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, Outdoor Temperature	S1-031-01916-000	1	1	1

POSITION 1 = ALL EXCEPT F
POSITION 5 & 6 = ALL EXCEPT E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = G
POSITION 10 = C HPC (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Sensor, Return Air Temperature	S1-031-01917-000	1	1	1
Sensor, Discharge Air Temperature	S1-031-01915-000	1	1	1
Terminal Block, 1 Pole	S1-025-32615-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	1	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	1	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = H, I, J
POSITION 10 = C HPC

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controller, 2HP, 3.6 Amp., 460V	S1-024-32028-007	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1

POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = H, I, J
POSITION 10 = C HPC (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 3/4HP, 208-230/460V, 3 Pole	S1-024-31439-000	1	-	-
Motor, Fan, 1 1/4HP, 460/380-415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	3	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Fan, Prop., 3 Bl., 24" Dia., 25 Deg., 5/8" Bore	S1-026-35581-000	1	-	-
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	2	2	2
Relay, Time Delay, 30 Sec	S1-024-32079-000	2	-	-
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Switch, Lockout, O Def F	S1-025-32743-000	1	1	1
Terminal Block, 1 Pole	S1-025-32615-000	-	2	-
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	1	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	1	-	-
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	-	-
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	-	1	1
Transducer, Pressure	S1-025-37463-000	2	2	2
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = D, E, F
POSITION 10 = C HPC

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controller, 2HP, 3.6 Amp., 460V	S1-024-32028-007	1	1	1
Controller, Synthesis	S1-031-01919-000	1	1	1

POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = D, E, F
POSITION 10 = C HPC (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Transducer, Duct Pressure	S1-031-01209-700	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06x	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 3/4HP, 208-230/460V, 3 Pole	S1-024-31439-000	1	-	-
Motor, Fan, 1 1/4HP, 460-380-415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	3	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Fan, Prop., 3 Bl., 24" Dia., 25 Deg., 5/8" Bore	S1-026-35581-000	1	-	-
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	2	2	2
Relay, Time Delay, 30 Sec	S1-024-32079-000	2	-	-
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, Return Air Temperature	S1-031-01917-000	1	1	1
Sensor, Discharge Air Temperature	S1-031-01915-000	1	1	1
Sensor, Outdoor Temperature	S1-031-01916-000	1	1	1
Switch, Lockout, O Def F	S1-025-32743-000	1	1	1
Terminal Block, 1 Pole	S1-025-32615-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	1	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	1	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	-	-
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	-	1	1
Transducer, Pressure	S1-025-37463-000	2	2	2
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 4

POSITION 8 = A, B, C, D

POSITION 14 = H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 1 1/4HP, 460/380/415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	4	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	1	1
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 4

POSITION 8 = M, N, O, P, Q, R

POSITION 14 = H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 1 1/4HP, 460/380/415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	4	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	2	2	2
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Terminal Block, 1 Pole	S1-025-32615-000	-	2	-
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	1	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	1	-	-

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 4

POSITION 8 = M, N, O, P, Q, R

POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	1	1
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 4

POSITION 8 = M, N, O, P, Q, R

POSITION 14 = D, E, F

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controller, Synthesis	S1-031-01919-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 1 1/4HP, 460/380/415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	4	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	2	2	2
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, Outdoor Temperature	S1-031-01916-000	1	1	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 4

POSITION 8 = M, N, O, P, Q, R

POSITION 14 = D, E, F (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Sensor, Return Air Temperature	S1-031-01917-000	1	1	1
Sensor, Discharge Air Temperature	S1-031-01915-000	1	1	1
Terminal Block, 1 Pole	S1-025-32615-000	2	2	2
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	1	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 1 = ALL EXCEPT F

POSITION 5 & 6 = E1, E4, E8

POSITION 7 = 4

POSITION 8 = M, N, O, P, Q, R

POSITION 14 = G

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	-
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 1 1/4HP, 460/380/415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	4	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	2	2	-

POSITION 1 = ALL EXCEPT F
POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = G (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, Outdoor Temperature	S1-031-01916-000	1	1	-
Sensor, Return Air Temperature	S1-031-01917-000	1	1	1
Sensor, Discharge Air Temperature	S1-031-01915-000	1	1	1
Terminal Block, 1 Pole	S1-025-32615-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	1	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	1	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	-	-
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	-	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 1 = ALL EXCEPT F
POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = G

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	-	-
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Contactor, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contactor, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Control, Pressure	S1-024-27557-000	1	-	-
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	-	-
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	-	-
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	-	-
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	-	-
Latch, Door Safety	S1-029-21185-000	1	-	-
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	-	-
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	4	-	-
Pressure, Tap	S1-023-16881-000	1	-	-
Resistor, 1K Ohm	S1-031-01914-000	1	-	-
Sensor, Return Air Temperature	S1-031-01917-000	1	-	-
Sensor, Discharge Air Temperature	S1-031-01915-000	1	-	-
Terminal Block, 1 Pole	S1-025-32615-000	2	-	-
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	-	-
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	1	-	-

POSITION 1 = ALL EXCEPT F
POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = G (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	-	-
Transformer, 460/575V	S1-025-37431-003	1	-	-

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8
POSITION 7 = 4
POSITION 8 = A, B, C, D
POSITION 14 = H, I, J
POSITION 10 = A HPC

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controller, 2HP, 3.6 Amp., 460V	S1-024-32028-007	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 3/4HP 208-230/460V, 3 Pole	S1-024-31439-000	1	-	-
Motor, Fan, 1 1/4HP, 460/380-415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	3	-	-
Pressure, Tap	S1-023-16881-000	1	1	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 4

POSITION 8 = A, B, C, D

POSITION 14 = H, I, J

POSITION 10 = A HPC (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Fan, Prop., 3 Bl., 24" Dia., 25 Deg., 5/8" Bore	S1-026-35581-000	1	-	-
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Switch, Lockout, O Def F	S1-025-32743-000	1	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	-	-
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	-	1	1
Transducer, Pressure	S1-025-37463-000	2	2	2
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 5 & 6 = E1, E4, E8

POSITION 7 = 4

POSITION 8 = A, B, C, D

POSITION 14 = H, I, J

POSITION 10 = A HPC

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2

POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = A, B, C, D
POSITION 14 = H, I, J
POSITION 10 = A HPC (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 1 1/4HP, 460/380-415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	3	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	-	-
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	-	1	1
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 1 = Y, F, G
POSITION 5 & 6 = ALL EXCEPT E1, E4, E8
POSITION 7 = 4
POSITION 8 = A, B, C, D
POSITION 13 = A, B, C
POSITION 14 = A, B, C

Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	-	-	1
Compressor, ZR12M3TWD	S1-015-02918-004	-	-	4
Contactor, Elec., 3 Pole	S1-024-26051-000	-	-	4
Contactor, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	-	4
Control, Pressure	S1-024-27557-000	-	-	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	-	-	2
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	-	12
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	-	2
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	-	5
Hinge, 4"	S1-029-22171-000	-	-	2

POSITION 1 = Y, F, G
POSITION 5 & 6 = ALL EXCEPT E1, E4, E8
POSITION 7 = 4
POSITION 8 = A, B, C, D
POSITION 13 = A, B, C
POSITION 14 = A, B, C (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Latch, Door Safety	S1-029-21185-000	-	-	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	-	-	1
Motor, Fan, 1 1/4HP, 460/380-415V, 3 Pole	S1-024-32068-002	-	-	4
Pressure, Tap	S1-023-16881-000	-	-	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	-	-	4
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	-	-	6
Relay, Time Delay, 30 Sec	S1-024-32079-000	-	-	4
Terminal Block, 1 Pole	S1-025-32615-000	-	-	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	-	-	2
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	-	-	1
Terminal Block, 10 Pole	S1-025-16100-000	-	-	1
Transformer, 24V TO 24V	S1-025-32699-000	-	-	1
Transformer, 460/575V	S1-025-37431-003	-	-	1

POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = A, B, C, D
POSITION 14 = H, I, J

Capacitor, Run, 15.0 MFD, 370V	S1-024-20446-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M3TWD	S1-015-03152-004	2	-	-
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contactor, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contactor, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contactor, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contactor, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	2	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5

POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 4
POSITION 8 = A, B, C, D
POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	2	-	-
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 1 1/4HP, 460/380-415V, 3 Pole	S1-024-32068-002	-	3	4
Motor, Fan, 3/4HP, 460-1-60V	S1-024-19878-000	4	-	-
Pressure, Tap	S1-023-16881-000	1	1	1
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	-	-
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	-	1	1
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 1 = ALL EXCEPT F
POSITION 5 & 6 = ALL EXCEPT E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = G

Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	-	1	1
Compressor, ZR12M3TWD	S1-015-02918-004	-	3	4
Contactor, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contactor, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	-	1	1
Transducer, Duct Pressure	S1-031-01209-700	-	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	-	2	2
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	-	3	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	-	3
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	-	9	12
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	2	2
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	4	5
Hinge, 4"	S1-029-22171-000	-	2	2
Latch, Door Safety	S1-029-21185-000	-	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	-	1	1
Motor, Fan, 1 1/4HP, 460/380-415V, 3 Pole	S1-024-32068-002	-	3	4
Pressure, Tap	S1-023-16881-000	-	1	1

POSITION 1 = ALL EXCEPT F
POSITION 5 & 6 = ALL EXCEPT E1, E4, E8
POSITION 7 = 4
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = G (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	-	2	2
Resistor, 1K Ohm	S1-031-01914-000	-	1	1
Sensor, Outdoor Temperature	S1-031-01916-000	-	1	1
Sensor, Return Air Temperature	S1-031-01917-000	-	1	1
Sensor, Discharge Air Temperature	S1-031-01915-000	-	1	1
Terminal Block, 1 Pole	S1-025-32615-000	-	2	2
Terminal Block, 1 Pole, 15 Amp., 150V	S1-025-32770-000	-	1	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	-	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	-	1	1
Transformer, 460/575V	S1-025-37431-003	-	1	1

575-3-60 VOLTAGE CODE 5 = NOMENCLATURE 7TH POSITION

POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 5
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = H, I, J

Capacitor, Run, 10/440	S1-024-31404-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M2TWE	S1-015-03153-004	2	-	-
Compressor, ZR12M3TWE	S1-015-02919-004	-	3	4
Contactor, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contactor, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contactor, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contactor, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 10 Amp., 600V, 13	S1-025-11910-000	2	3	-
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	-	-	3
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	-	9	12
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	6	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	2	4	5
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1

POSITION 5 & 6 = E1, E4, E8
POSITION 7 = 5
POSITION 8 = M, N, O, P, Q, R
POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 3/4HP, 575V	S1-024-31408-000	4	-	-
Motor, Fan, 1 1/4HP, 460/380-415V, 3 Pole	S1-024-32068-003	-	3	4
Pressure, Tap	S1-023-16881-000	1	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	2	-	-
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	2	2	2
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Terminal Block, 1 Pole	S1-025-32615-000	-	2	-
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	1	1
Terminal Block, 2 Pole, 20 Amp., 250V	S1-025-30887-000	1	-	-
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	-	-
Terminal Block, 3 Pole, 760 Amp., 600V	S1-025-30110-000	-	1	1
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8
POSITION 7 = 5
POSITION 8 = A, B, C, D
POSITION 14 = H, I, J

Capacitor, Run, 10/440	S1-024-31404-000	4	-	-
Circuit Breaker, 12 Amp., 250V	S1-024-34578-000	1	1	1
Circuit Breaker, 1 Pole, 3.2 Amp., 250V	S1-024-34532-000	1	1	1
Compressor, ZR16M2TWE	S1-015-03153-004	2	-	-
Compressor, ZR12M3TWE	S1-015-02919-004	-	3	4
Contact, Elec., 3 Pole, 40 Amp., 24V, 50/60 Hz	S1-024-25844-000	2	-	-
Contact, Elec., 2 Pole, 20 Amp., 24V, 50/60 Hz	S1-024-24101-000	4	-	-
Contact, Elec., 3 Pole	S1-024-26051-000	-	4	4
Contact, Elec., 3 Pole, 30 Amp., 24V, 50/60 Hz	S1-024-25955-000	-	3	4
Control, Pressure	S1-024-27557-000	1	1	1
Controls, PCB	S1-031-01997-000	1	1	1
Fuse, Dual, #1, 1.5 Amp., 600V, Time Delay, CC	S1-025-27750-000	2	2	2
Fuse, Dual, 10 Amp., 600V, 13	S1-025-11910-000	2	3	-
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	-	-	3
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	-	9	12
Fuse, Dual, 30 Amp., 600V, 13 x 16 x 5	S1-025-04650-000	6	-	-

POSITION 5 & 6 = ALL EXCEPT E1, E4, E8

POSITION 7 = 5

POSITION 8 = A, B, C, D

POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Fuseholder, #23, 30 Amp., 600V, 2 Pole	S1-025-14213-000	1	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	3	4	5
Hinge, 4"	S1-029-22171-000	2	2	2
Latch, Door Safety	S1-029-21185-000	1	1	1
Lug, Electrical, 14-1/0 W	S1-025-19282-000	1	1	1
Motor, Fan, 3/4HP, 575V	S1-024-31408-000	4	-	-
Motor, Fan, 1 1/4HP, 460/380-415V, 3 Pole	S1-024-32068-003	-	3	4
Pressure, Tap	S1-023-16881-000	1	1	1
Resistor, 1K Ohm	S1-031-01914-000	1	1	1
Sensor, 10K Ohm, Return & Outdoor Temperature	S1-031-09130-000	2	2	2
Sensor, Supply Temperature	S1-031-09129-000	1	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	2	2	2
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	1	1
Terminal Block, 3 Pole, 335 Amp., 600V	S1-025-20573-000	1	1	1
Transformer, 208/230/460V, 50/60 Hz	S1-025-33469-000	1	1	1
Transformer, 460/575V	S1-025-37431-003	1	1	1

REFRIGERATION COMPONENTS (Beginning Reference - Position 10 in Unit Model)

CONDENSER COIL

Coil, Condenser, RH	S1-373-21733-100	1	-	-
Header, System 2	S1-373-21733-060	1	-	-
Header, System 1	S1-373-21733-050	1	-	-
Coil, Condenser, LH	S1-373-21734-100	1	-	-
Header, System 2	S1-373-21733-060	1	-	-
Header, System 1	S1-373-21733-050	1	-	-
Coil, Condenser	S1-373-15295-001	-	1	1
Header, 1-1/8"	S1-373-15295-050	-	1	1
Header, 5/8"	S1-373-15295-060	-	1	1
Distributor, 2 Feed	S1-026-25559-000	-	1	1
Coil, Condenser	S1-373-15960-001	-	1	1
Header, 1-1/8"	S1-373-15295-050	-	1	1
Header, 5/8"	S1-373-15295-060	-	1	1
Distributor, 2 Feed	S1-026-25559-000	-	1	1

EVAPORATOR COIL & PIPING COMPONENTS

POSITION 10 = C, D, K, L

POSITION 14 = D, E, F, G, H, I, J

Coil, Evaporator	S1-373-21995-106	1	-	-
Coil, Evaporator	S1-373-17165-105	-	1	-
Coil, Evaporator	S1-373-17165-105	-	-	1

POSITION 10 = C, D, K, L

POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
TXV-Distributor Assy., 18 Tube	S1-025-33471-000	1	-	-
TXV-Distributor Assy., 18 Tube, w/HGBP	S1-025-33472-000	1	-	-
TXV-Distributor Assy., 12 Tube	S1-025-32658-001	-	3	-
TXV-Distributor Assy., 14 Tube	S1-025-32658-002	-	-	4
Valve, Thermal Expansion	S1-022-08912-000	-	3	4
Adapter, Nozzle, Size 4	S1-022-08985-000	-	1	1
Hot Gas Bypass	S1-022-08989-000	1	1	1
Core, V Port	S1-022-02475-000	14	17	17
Stem, Valve	S1-022-08017-000	14	17	17
Filter Drier	S1-026-35458-000	2	-	-
Filter Drier	S1-026-35475-000	-	3	3
Indicator, Moisture	S1-026-15305-000	2	-	-
Indicator, Moisture	S1-026-12865-000	-	3	3
Control, Pressure	S1-025-33450-000	2	3	3
Control, Pressure	S1-025-33451-000	2	3	3
Control, Refrigerant	S1-025-38404-000	2	2	2

POSITION 10 = A,B, I, J

POSITION 14 = D, E, F, G, H, I, J

Coil, Evaporator	S1-373-21995-105	1	-	-
Coil, Evaporator	S1-373-17165-104	-	1	-
Coil, Evaporator	S1-373-17165-106	-	-	1
TXV-Distributor Assy., 18 Tube	S1-025-33471-000	2	-	-
TXV-Distributor Assy., 12 Tube	S1-025-32658-001	-	3	-
TXV-Distributor Assy., 14 Tube	S1-025-32658-002	-	-	4
Valve, Thermal Expansion	S1-022-08912-000	-	3	4
Core, V Port	S1-022-02475-000	14	17	22
Stem, Valve	S1-022-08017-000	14	17	22
Filter Drier	S1-026-35458-000	2	3	4
Indicator, Moisture	S1-026-15305-000	2	3	4
Control, Pressure	S1-025-33450-000	2	3	4
Control, Pressure	S1-025-33451-000	2	3	4
Control, Refrigerant	S1-025-38404-000	2	3	4

POSITION 10 = E, F, M, N

POSITION 14 = D, E, F, G, H, I, J

Coil, Evaporator	S1-373-17165-106	-	1	-
Coil, Evaporator	S1-373-17354-109	-	-	1
TXV-Distributor Assy., 16 Tube	S1-025-32685-000	-	3	-
TXV-Distributor Assy., 14 Tube	S1-025-32658-002	-	-	4
Valve, TXV	S1-022-08992-000	-	3	-
Valve, TXV	S1-022-08912-000	-	-	4
Hot Gas Bypass	S1-022-08989-000	-	-	1
Core, V Port	S1-022-02475-000	-	17	22
Stem, Valve	S1-022-08017-000	-	17	22
Filter Drier	S1-026-35475-000	-	3	4
Indicator, Moisture	S1-026-12865-000	-	3	4
Control, Pressure	S1-025-33450-000	-	3	4

POSITION 10 = E, F, M, N

POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Control, Pressure	S1-025-33451-000	-	3	4
Control, Refrigerant	S1-025-38404-000	-	2	2

POSITION 10 = G, H, O, P

POSITION 14 = D, E, F, G, H, I, J

Coil, Evaporator	S1-373-17354-108	-	-	1
TXV-Distributor Assy., 14 Tube	S1-025-32658-002	-	-	4
Core, V Port	S1-022-02475-000	-	-	22
Stem, Valve	S1-022-08017-000	-	-	22
Filter Drier	S1-026-35475-000	-	-	4
Indicator Moisture	S1-026-12865-000	-	-	4
Control, Pressure	S1-025-33450-000	-	-	4
Control, Pressure	S1-025-33451-000	-	-	4
Control, Refrigerant	S1-025-38404-000	-	-	2

POSITION 10 = E, F, M, N

POSITION 14 = A, B, C

Coil, Evaporator	S1-373-17354-102	-	-	1
TXV-Distributor Assy., 14 Tube	S1-025-32658-002	-	-	4
Valve, Thermal Expansion	S1-022-08912-000	-	-	4
Core, V Port	S1-022-02475-000	-	-	22
Stem, Valve	S1-022-08017-000	-	-	22
Filter Drier	S1-026-35475-000	-	-	4
Indicator, Moisture	S1-026-12865-000	-	-	4
Control, Pressure, HP	S1-025-17620-114	-	-	4
Control, Pressure, LP1	S1-025-32621-000	-	-	1
Control, Refrigerant	S1-025-38404-000	-	-	2
Control, Pressure, LP3	S1-025-33314-000	-	-	1
Control, Pressure, LP2	S1-025-33314-000	-	-	1
Control, Pressure, LP2	S1-025-33314-000	-	-	1

INDOOR BLOWER INCLUDING MOTOR (Beginning Reference - Position 8 in Unit Model)

208/230-3-60 VOLTAGE CODE 2 = NOMENCLATURE 7TH POSITION

POSITION 7 = 2

POSITION 8 = A

POSITION 9 = 3

POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX610	S1-028-14711-000	-	2	-
Belt, V, 5VX710 71.0	S1-028-13296-000	-	-	2
Belt, V, BX56	S1-028-14709-000	2	-	-
Contact, Aux Switch	S1-024-25182-000	1	1	1
Element, Heater, OL	S1-024-19629-000	3	3	3
Fuse, Dual, 100 Amp., 250V, 3/4X	S1-025-16371-000	3	3	3
Fuseholder, #5, 100 Amp., 250V, 3 Pole	S1-025-26395-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 20HP, 230/460V	S1-024-25081-700	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1

POSITION 7 = 2
POSITION 8 = A
POSITION 9 = 3
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Sheave, 2B5V56	S1-028-14717-000	-	-	1
Sheave, 2B5V66 Bore	S1-028-12071-700	-	1	-
Sheave, 2B5V68	S1-028-12308-000	1	-	-
Starter	S1-024-26015-000	1	1	1

POSITION 7 = 2
POSITION 8 = A
POSITION 9 = 4
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX710 71.0	S1-028-13296-000	-	-	2
Contact, Aux Switch	S1-024-25182-000	-	-	1
Element, Heater, OL Furnas K83	S1-024-25386-000	-	-	3
Fuse, Dual, 110 Amp., 250V, 1.56X	S1-025-29042-000	-	-	3
Fuseholder, #5, 100 Amp., 250V, 3 Pole	S1-025-26395-000	-	-	1
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 25HP, 230/460V	S1-024-25082-700	-	-	1
Sheave, 2B5V136 Bore	S1-028-13273-000	-	-	1
Sheave, 2B5V60 Bore	S1-028-13271-000	-	-	1
Spring, Isolator	S1-029-20434-000	-	-	4
Starter, 90 Amp., 24V, Coil	S1-024-26016-000	-	-	1

POSITION 7 = 2
POSITION 8 = M
POSITION 9 = 4
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX710 71.0	S1-028-13296-000	-	-	2
Contact, Aux Switch	S1-024-25919-000	-	-	1
Element, Heater, OL Furnas K69	S1-024-19632-000	-	-	3
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	-	-	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	-	-	1
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 20HP, 230/460V	S1-024-25081-700	-	-	1
Sheave, 2B5V136 Bore	S1-028-13273-000	-	-	1
Sheave, 2B5V56	S1-028-14717-000	-	-	1
Spring, Isolator	S1-029-20434-000	-	-	4
Starter, Furnace, 30 Amp.	S1-024-27527-000	-	-	1

POSITION 7 = 2
POSITION 8 = M
POSITION 9 = 8
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX680 68.0	S1-028-14749-000	-	-	2
Belt, V, BX56	S1-028-14709-000	-	2	-
Controller, VFD, 25HP, 208/230V	S1-024-34519-000	-	1	1
Fuse, Dual, 110 Amp., 250V, 1.56X	S1-025-29042-000	-	3	3
Fuseholder, #6, 200 Amp., 250V, 3 Pole	S1-025-27715-000	-	1	1

POSITION 7 = 2
POSITION 8 = M
POSITION 9 = 8
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Housing, Blower, FC, 30T	S1-026-34629-000	-	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 25HP	S1-024-27589-000	-	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	-	1	1
Sheave, 2B5V56	S1-028-14717-000	-	1	-
Sheave, Fixed, 2 Groove	S1-028-13269-000	-	-	1
Spring, Isolator	S1-029-20434-000	-	4	4
Terminal, Grounding	S1-025-29006-000	-	1	1

POSITION 7 = 2
POSITION 8 = M
POSITION 9 = 9
POSITION 14 = D, E, F, G, H, I, J

Belt, V, BX56	S1-028-14709-000	2	-	-
Controller, VFD, 7.5HP, 208/230V	S1-024-34512-000	1	-	-
Fuse, Dual, 35 Amp., 600V, 1 1/6X	S1-025-18540-000	3	-	-
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	1	-	-
Housing, Blower, FC, 30T	S1-026-34629-000	1	-	-
Motor, Blower, 7.5HP, 230/460V	S1-024-25078-700	1	-	-
Sheave, 2B5V136 Bore	S1-028-13273-000	1	-	-
Sheave, 2B5V42	S1-028-14715-000	1	-	-
Spring, Isolator	S1-029-20434-000	4	-	-
Terminal, Grounding	S1-025-29006-000	1	-	-

POSITION 7 = 2
POSITION 8 = Q
POSITION 9 = 1
POSITION 14 = D, E, F, G, H, I, J

Belt, V, BX56	S1-028-14709-000	2	2	-
Belt, V, BX67	S1-028-14710-000	-	-	2
Controller, Bypass, 10HP, 208/230V	S1-024-34513-001	1	1	1
Fuse, Dual, 50 Amp., 250V, .40X	S1-025-26336-000	3	3	3
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 10HP, 200/208-230/460V	S1-024-25079-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V42	S1-028-14715-000	-	-	1
Sheave, 2B5V52 Bore	S1-028-13270-000	1	-	-
Sheave, 2 Groove, 2B5V46	S1-028-13358-000	-	1	-
Terminal, Grounding	S1-025-29006-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1

460-3-60 VOLTAGE CODE 4 = NOMENCLATURE 7TH POSITION
POSITION 7 = 4
POSITION 8 = A
POSITION 9 = 0
POSITION 14 = D, E, F, G, H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Contact, Aux Switch	S1-024-25919-000	1	-	-
Element, Heater, OL Furnas	S1-024-19099-000	3	-	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	3	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	-	-
Housing, Blower, FC, 30T	S1-026-34629-000	1	-	-
Motor, Blower, 7.5HP, 230/460V, 213T, 1750 RPM Nom	S1-024-27525-000	1	-	-
Spring, Isolator	S1-029-20434-000	4	-	-
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	-	-

POSITION 7 = 4
POSITION 8 = A
POSITION 9 = 1
POSITION 14 = D, E, F, G, H, I, J

Belt, V, BX56	S1-028-14709-000	2	2	-
Belt, V, BX67	S1-028-14710-700	-	-	2
Contact, Aux Switch	S1-024-25919-000	1	1	1
Element, Heater, OL Furnas K57	S1-024-19422-000	3	3	3
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 10HP, 200/208-230/460V	S1-024-25079-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V42	S1-028-14715-000	-	-	1
Sheave, 2B5V52 Bore	S1-028-13270-000	1	-	-
Sheave, 2 Groove, 2B5V46	S1-028-13358-000	-	1	-
Spring, Isolator	S1-029-20434-000	4	4	4
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1

POSITION 7 = 4
POSITION 8 = A
POSITION 9 = 2
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX680 68.0	S1-028-14749-000	-	-	2
Belt, V, BX56	S1-028-14709-000	2	2	-
Element, Heater, OL Furnas K63	S1-024-21055-000	3	3	3
Element, Heater, OL Furnas K63	S1-024-21055-000	3	3	3
Fuse, Dual, 35 Amp., 600V, 1 1/6X	S1-025-18540-000	3	3	3
Fuse, Dual, 35 Amp., 600V, 1 1/6X	S1-025-18540-000	3	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	1	1	1
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	1	1	1

POSITION 7 = 4
POSITION 8 = A
POSITION 9 = 2
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 15HP, 230/460V	S1-024-25080-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V56	S1-028-14717-000	-	1	-
Sheave, 2B5V60 Bore	S1-028-13271-000	1	-	-
Sheave, Fixed, 2 Groove	S1-028-13269-000	-	-	1
Spring, Isolator	S1-029-20434-000	4	4	4
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1

POSITION 7 = 4
POSITION 8 = A
POSITION 9 = 3
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX610	S1-028-14711-000	-	2	-
Belt, V, 5VX710 71.0	S1-028-13296-000	-	-	2
Belt, V, BX56	S1-028-14709-000	2	-	-
Contactor, Aux Switch	S1-024-25919-000	1	1	1
Element, Heater, OL Furnas K69	S1-024-19632-000	3	3	3
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	3	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 20HP, 230/460V	S1-024-25081-700	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V56	S1-028-14717-000	-	-	1
Sheave, 2B5V66 Bore	S1-028-12071-700	-	1	-
Sheave, 2B5V68	S1-028-12308-700	1	-	-
Spring, Isolator	S1-029-20434-000	4	4	4
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1

POSITION 7 = 4
POSITION 8 = A
POSITION 9 = 5
POSITION 14 = D, E, F, G, H, I, J

Belt, V, BX56	S1-028-14709-000	2	2	-
Contactor, Aux Switch	S1-024-25919-000	1	1	1
Element, Heater, OL Furnas K57	S1-024-19422-000	3	3	3
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 10HP, 230/460V, D215T, 1800 Rpm	S1-024-26005-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	-

POSITION 7 = 4
POSITION 8 = A
POSITION 9 = 5
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Sheave, 2B5V52 Bore	S1-028-13270-000	1	-	-
Sheave, 2 Groove, 2B5V46	S1-028-13358-000	-	1	-
Spring, Isolator	S1-029-20434-000	4	4	4
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1

POSITION 7 = 4
POSITION 8 = A
POSITION 9 = 7
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX610	S1-028-14711-000	-	2	-
Belt, V, BX56	S1-028-14709-000	2	-	-
Contactor, Aux Switch	S1-024-25919-000	1	1	1
Element, Heater, OL Furnas K69	S1-024-19632-000	3	3	3
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	3	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 20HP, 1800	S1-024-25992-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V56	S1-028-14717-000	-	-	1
Sheave, 2B5V66 Bore	S1-028-12071-700	-	1	-
Sheave, 2B5V68	S1-028-12308-700	1	-	-
Spring, Isolator	S1-029-20434-000	4	4	4
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1

POSITION 7 = 4
POSITION 8 = A
POSITION 9 = 3
POSITION 14 = A, B, C

Belt, V, 5VX710 71.0	S1-028-13296-000	-	-	2
Contactor, Aux Switch	S1-024-25919-000	-	-	1
Element, Heater, OL Furnas K69	S1-024-19632-000	-	-	3
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	-	-	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	-	-	1
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 20HP, 230/460V	S1-024-25081-700	-	-	1
Sheave, 2B5V136 Bore	S1-028-13273-000	-	-	1
Sheave, 2B5V56	S1-028-14717-000	-	-	1
Spring, Isolator	S1-029-20434-000	-	-	4
Starter, Furnace, 30 Amp.	S1-024-27527-000	-	-	1

POSITION 7 = 4
POSITION 8 = C
POSITION 9 = 9
POSITION 14 = D, E, F, G, H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Belt, V, BX56	S1-028-14709-000	2	-	-
Contactor, Aux Switch	S1-024-25919-000	1	-	-
Element, Heater, OL Furnas	S1-024-19099-000	3	-	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	3	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	-	-
Housing, Blower, FC, 30T	S1-026-34629-000	1	-	-
Isolator, Spring, 2"	S1-029-21141-000	4	-	-
Motor, Blower, 7.5HP, 230/460V	S1-024-25078-700	1	-	-
Sheave, 2B5V136 Bore	S1-028-13273-000	1	-	-
Sheave, 2B5V42	S1-028-14715-000	1	-	-
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	-	-

POSITION 7 = 4
POSITION 8 = C
POSITION 9 = 8
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX610	S1-028-14711-000	-	2	-
Belt, V, 5VX710 71.0	S1-028-13296-000	-	-	2
Contactor, Aux Switch	S1-024-25919-000	-	1	1
Fuse, Dual, 50 Amp., 600V, 1 1/6X	S1-025-16411-000	-	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	-	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	-	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 25HP	S1-024-27589-000	-	1	1
Overload, Elec'l Metal	S1-024-25046-000	-	3	3
Sheave, 2B5V70	S1-028-12072-700	-	1	-
Sheave, 2B5V136 Bore	S1-028-13273-000	-	1	1
Sheave, 2B5V60 Bore	S1-028-13271-000	-	-	1
Starter, Furnace, 40 Amp.	S1-024-27528-000	-	1	1

POSITION 7 = 4
POSITION 8 = M
POSITION 9 = 6
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX680 68.0	S1-028-14749-000	-	-	2
Belt, V, BX56	S1-028-14709-000	2	2	-
Controller, VFD, 15HP, 460V	S1-024-34506-000	1	1	1
Fuse, Dual, 35 Amp., 600V, 1 1/6X	S1-025-18540-000	3	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	1
Motor, Blower, 15HP, 230/460V	S1-024-27526-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V56	S1-028-14717-000	-	1	-
Sheave, 2B5V60 Bore	S1-028-13271-000	1	-	-
Sheave, Fixed, 2 Groove	S1-028-13269-000	-	-	1

POSITION 7 = 4
POSITION 8 = M
POSITION 9 = 6
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Spring, Isolator	S1-029-20434-000	4	4	4
Terminal, Grounding	S1-025-29006-000	1	1	1

POSITION 7 = 4
POSITION 8 = N
POSITION 9 = 2
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX680 68.0	S1-028-14749-000	-	-	2
Belt, V, BX56	S1-028-14709-000	-	2	-
Controller, VFD, 15HP, 460V	S1-024-34506-000	-	1	1
Fuse, Dual, 35 Amp., 600V, 1 1/6X	S1-025-18540-000	-	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	-	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	-	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Isolator, Spring, 2"	S1-029-21141-000	-	4	4
Motor, Blower, 15HP, 230/460V	S1-024-25080-000	-	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	-	1	1
Sheave, 2B5V56	S1-028-14717-000	-	1	-
Sheave, Fixed, 2 Groove	S1-028-13269-000	-	-	1
Terminal, Grounding	S1-025-29006-000	-	1	1

POSITION 7 = 4
POSITION 8 = N
POSITION 9 = 6
POSITION 14 = E, F, I, J

Belt, V, 5VX680 68.0	S1-028-14749-000	-	-	2
Belt, V, BX56	S1-028-14709-000	2	2	-
Controller, VFD, 15HP, 460V	S1-024-34506-000	1	1	1
Fuse, Dual, 35 Amp., 600V, 1 1/6X	S1-025-18540-000	3	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Isolator, Spring, 2"	S1-029-21141-000	4	4	4
Motor, Blower, 15HP, 230/460V	S1-024-27526-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V56	S1-028-14717-000	-	1	-
Sheave, 2B5V60 Bore	S1-028-13271-000	1	-	-
Sheave, Fixed, 2 Groove	S1-028-13269-000	-	-	1
Terminal, Grounding	S1-025-29006-000	1	1	1

POSITION 7 = 4
POSITION 8 = N
POSITION 9 = 8
POSITION 14 = D, E, F, G, H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Belt, V, 5VX610	S1-028-14711-000	-	2	-
Belt, V, 5VX710 71.0	S1-028-13296-000	-	-	2
Controller, VFD, 25HP, 460V	S1-024-34508-000	-	1	1
Fuse, Dual, 50 Amp., 600V, 1 1/6X	S1-025-16411-000	-	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	-	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	-	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 25HP	S1-024-27589-000	-	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	-	1	1
Sheave, 2B5V60 Bore	S1-028-13271-000	-	-	1
Sheave, 2B5V70	S1-028-12072-700	-	1	-
Spring, Isolator	S1-029-20434-000	-	4	4
Terminal, Grounding	S1-025-29006-000	-	1	1

POSITION 7 = 4
POSITION 8 = N
POSITION 9 = 9
POSITION 14 = D, E, F, G, H, I, J

Belt, V, BX56	S1-028-14709-000	2	-	-
Controller, VFD, 7.5HP, 460V	S1-024-34504-000	1	-	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	3	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	-	-
Housing, Blower, FC, 30T	S1-026-34629-000	1	-	-
Isolator, Spring, 2"	S1-029-21141-000	4	-	-
Motor, Blower, 7.5HP, 230/460V	S1-024-25078-700	1	-	-
Sheave, 2B5V136 Bore	S1-028-13273-000	1	-	-
Sheave, 2B5V42	S1-028-14715-000	1	-	-

POSITION 7 = 4
POSITION 8 = Q
POSITION 9 = 0
POSITION 14 = D, E, F, G, H, I, J

Belt, V, BX56	S1-028-14709-000	2	-	-
Controller, VFD, Bypass, 7.5HP, 460V	S1-024-34504-001	1	-	-
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	3	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	-	-
Housing, Blower, FC, 30T	S1-026-34629-000	1	-	-
Motor, Blower, 7.5HP, 230/460V, 213T, 1750 RPM Nom	S1-024-27525-000	1	-	-
Sheave, 2B5V136 Bore	S1-028-13273-000	1	-	-
Sheave, 2B5V42	S1-028-14715-000	1	-	-
Terminal, Grounding	S1-025-29006-000	1	-	-
Transducer, Duct Pressure	S1-031-01209-700	1	-	-

POSITION 7 = 4
POSITION 8 = Q
POSITION 9 = 1
POSITION 14 = D, E, F, G, H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Belt, V, BX56	S1-028-14709-000	2	-	-
Controller, VFD, Bypass, 10HP, 460V	S1-024-34505-001	1	-	-
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	3	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	-	-
Housing, Blower, FC, 30T	S1-026-34629-000	1	-	-
Motor, Blower, 10HP, 200/208-230/460V	S1-024-25079-000	1	-	-
Sheave, 2B5V136 Bore	S1-028-13273-000	1	-	-
Sheave, 2B5V52 Bore	S1-028-13270-000	1	-	-
Terminal, Grounding	S1-025-29006-000	1	-	-
Transducer, Duct Pressure	S1-031-01209-700	1	-	-

POSITION 7 = 4
POSITION 8 = Q
POSITION 9 = 4
POSITION 14 = D, E, F, G, H, I, J

Controller, VFD, Bypass, 25HP, 460V	S1-024-34508-001	-	1	1
Fuse, Dual, 50 Amp., 600V, 1 1/6X	S1-025-16411-000	-	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	-	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	-	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 25HP, 230/460V	S1-024-25082-000	-	1	1
Terminal, Grounding	S1-025-29006-000	-	1	1
Transducer, Duct Pressure	S1-031-01209-700	-	1	1

POSITION 7 = 4
POSITION 8 = Q
POSITION 9 = 5
POSITION 14 = D, E, F, G, H, I, J

Belt, V, BX56	S1-028-14709-000	2	2	-
Belt, V, BX67	S1-028-14710-000	-	-	2
Controller, VFD, Bypass, 10HP, 460V	S1-024-34505-001	1	1	1
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 10HP, 230/460V, D215T, 1800 Rpm	S1-024-26005-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V42	S1-028-14715-000	-	-	1
Sheave, 2B5V52 Bore	S1-028-13270-000	1	-	-
Sheave, 2 Groove, 2B5V46	S1-028-13358-000	-	1	-
Spring, Isolator	S1-029-20434-000	4	4	4
Terminal, Grounding	S1-025-29006-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1

POSITION 7 = 4
POSITION 8 = Q
POSITION 9 = 6
POSITION 14 = D, E, F, G, H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Belt, V, BX56	S1-028-14709-000	2	2	-
Controller, VFD, Bypass, 15HP, 460V	S1-024-34506-001	1	1	1
Fuse, Dual, 35 Amp., 600V, 1 1/6X	S1-025-18540-000	3	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 15HP, 230/460V	S1-024-27526-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	-
Sheave, 2B5V56	S1-028-14717-000	-	1	-
Sheave, 2B5V60 Bore	S1-028-13271-000	1	-	-
Terminal, Grounding	S1-025-29006-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1

POSITION 7 = 4
POSITION 8 = Q
POSITION 9 = 7
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX610	S1-028-14711-000	-	2	-
Belt, V, 5VX710 71.0	S1-028-13296-000	-	-	2
Belt, V, BX56	S1-028-14709-000	2	-	-
Controller, VFD, Bypass, 20HP, 460V	S1-024-34507-001	1	1	1
Fuse, Dual, 40 Amp., 600V, 1.06X	S1-025-20985-000	3	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 20HP, 1800	S1-024-25992-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V56	S1-028-14717-000	-	-	1
Sheave, 2B5V66 Bore	S1-028-12071-700	-	1	-
Sheave, 2B5V68	S1-028-12308-700	1	-	-
Terminal, Grounding	S1-025-29006-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1

POSITION 7 = 4
POSITION 8 = Q
POSITION 9 = 8
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX610	S1-028-14711-000	-	2	-
Belt, V, 5VX710 71.0	S1-028-13296-000	-	-	2
Controller, VFD, 25HP, 460V	S1-024-34508-000	-	1	1
Fuse, Dual, 50 Amp., 600V, 1 1/6X	S1-025-16411-000	-	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	-	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	-	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 25HP	S1-024-27589-000	-	1	1

POSITION 7 = 4
POSITION 8 = Q
POSITION 9 = 8
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Sheave, 2B5V136 Bore	S1-028-13273-000	-	1	1
Sheave, 2B5V60 Bore	S1-028-13271-000	-	-	1
Sheave, 2B5V70	S1-028-12072-700	-	1	-
Spring, Isolator	S1-029-20434-000	-	4	4
Terminal, Grounding	S1-025-29006-000	-	1	1

POSITION 7 = 4
POSITION 8 = R
POSITION 9 = 5
POSITION 14 = D, E, F, G, H, I, J

Belt, V, BX56	S1-028-14709-000	2	2	-
Belt, V, BX67	S1-028-14710-000	-	-	2
Controller, VFD, Bypass, 10HP, 460V	S1-024-34505-001	1	1	1
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 10HP, 230/460V, D215T, 1800 Rpm	S1-024-26005-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V42	S1-028-14715-000	-	-	1
Sheave, 2B5V52 Bore	S1-028-13270-000	1	-	-
Sheave, 2 Groove, 2B5V46	S1-028-13358-000	-	1	-
Terminal, Grounding	S1-025-29006-000	1	1	1
Transducer, Duct Pressure	S1-031-01209-700	1	1	1

575-3-60 VOLTAGE CODE 5 = NOMENCLATURE 7TH POSITION

POSITION 7 = 5
POSITION 8 = M
POSITION 9 = 2
POSITION 14 = D, E, F, G, H, I, J

Belt, V, 5VX680 68.0	S1-028-14749-000	-	-	2
Belt, V, BX56	S1-028-14709-000	2	2	-
Controller, VFD, 15HP, 575V	S1-024-34514-000	1	1	1
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Housing, Blower, FC, 30T	S1-026-34629-000	1	1	-
Housing, Blower, FC, 40T	S1-026-34631-000	-	-	1
Motor, Blower, 15.0HP, 575V	S1-024-27619-000	1	1	1
Sheave, 2B5V136 Bore	S1-028-13273-000	1	1	1
Sheave, 2B5V56	S1-028-14717-000	-	1	-
Sheave, 2B5V60 Bore	S1-028-13271-000	1	-	-
Sheave, Fixed, 2 Groove	S1-028-13269-000	-	-	1
Terminal, Grounding	S1-025-29006-000	1	1	1

EXHAUST (Beginning Reference - Position 12 in Unit Model)**NO EXHAUST****POSITION 4 = A, B, C, D, E, F****POSITION 12 = N**

Description	Part Number	Model		
		Y22	Y23	Y24
Panel, Rear Lower	S1-373-17127-000	1	1	1

WITH EXHAUST**208/230-3-60 VOLTAGE CODE 2 = NOMENCLATURE 7TH POSITION****POSITION 7 = 2****POSITION 12 = B****POSITION 14 = D, E, F, G, H, I, J**

Actuator	S1-025-33490-000	1	1	1
Ball Joint, TY, DC Superior	S1-029-08786-000	2	2	2
Belt, V, B62, 63.8	S1-028-08781-000	2	2	2
Blower, Dual	S1-026-34671-000	1	1	1
Crankarm	S1-029-22116-000	1	1	1
Element, Heater	S1-024-19631-000	3	3	3
Fuse, Dual, 35 Amp., 250V, 13 x 16 x 3	S1-025-15491-000	3	3	3
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	1	1	1
Motor, 7.5HP, 230/460V	S1-024-25078-700	1	1	1
Panel, Hood, Bottom	S1-073-16157-000	1	1	1
Panel, Hood, Side	S1-073-16155-000	1	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1
Panel, Hood, Top	S1-073-16154-000	1	1	1
Sheave, 2B5V52 Bore	S1-028-13270-000	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1
Transducer, Pressure	S1-031-01262-000	1	1	1

POSITION 7 = 2**POSITION 12 = D****POSITION 14 = D, E, F, G, H, I, J**

Actuator	S1-025-33490-000	-	-	1
Ball Joint, TY, DC Superior	S1-029-08786-000	-	-	2
Belt, V, B62, 63.8	S1-028-08781-000	-	-	2
Blower, Dual	S1-026-34671-000	-	-	1
Crankarm	S1-029-22116-000	-	-	1
Element, Heater	S1-024-25343-700	-	-	3
Fuse, Dual, 70 Amp., 250V, 3/4X	S1-025-18539-000	-	-	3
Fuseholder, #5, 100 Amp., 250V, 3 Pole	S1-025-26395-000	-	-	1
Motor, 15HP, 230/460V	S1-024-25080-000	-	-	1
Panel, Hood, Bottom	S1-073-16157-000	-	-	1
Panel, Hood, Side	S1-073-16155-000	-	-	1
Panel, Hood, Side	S1-073-16156-000	-	-	1
Panel, Hood, Top	S1-073-16154-000	-	-	1
Sheave, 2B5V66 Bore	S1-028-12071-700	-	-	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	-	-	1
Starter, Furnace, 50 Amp.	S1-024-27529-000	-	-	1
Transducer, Pressure	S1-031-01262-000	-	-	1

POSITION 7 = 2
POSITION 12 = V
POSITION 14 = D, E, F, G, H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Belt, V, B62, 63.8	S1-028-08781-000	-	2	2
Blower, Dual	S1-026-34671-000	-	1	1
Controller, VFD, 7.5HP, 208/230V	S1-024-34512-000	-	1	1
Fuse, Dual, 70 Amp., 250V	S1-025-18539-000	-	-	-
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	-	1	1
Motor, Blower, 7.5HP, 230/460V, 213T, 1750 RPM Nom	S1-024-27525-000	-	1	1
Panel, Hood, Top	S1-073-16154-000	-	1	1
Panel, Hood, Bottom	S1-073-16157-000	-	1	1
Panel, Hood, Side	S1-073-16155-000	-	1	1
Panel, Hood, Side	S1-073-16156-000	-	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	-	1	1
Sheave, 2B5V52 Bore	S1-028-13270-000	-	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	-	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	-	1	1
Timer, Anti-Short Cycle	S1-031-00829-000	-	1	1
Transducer, Pressure	S1-031-01262-000	-	1	1
Transducer, Pressure	S1-031-01977-000	-	1	1

POSITION 7 = 2
POSITION 12 = Y
POSITION 14 = D, E, F, G, H, I, J

Belt, V, B62, 63.8	S1-028-08781-000	2	-	-
Blower, 15 x 15, Single	S1-026-35579-000	1	-	-
Controller, VFD, 5HP, 460V	S1-024-34502-000	1	-	-
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	3	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	-	-
Motor, Blower, 5HP, 230/460V	S1-024-27591-001	1	-	-
Panel, Hood, Side	S1-073-16155-000	1	-	-
Panel, Hood, Side	S1-073-16156-000	1	-	-
Panel, Hood, Top	S1-073-21888-000	1	-	-
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	1	-	-
Sheave, 2 Groove, 2B5V46	S1-028-13358-000	1	-	-
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	-	-
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	-	-
Timer, Anti-Short Cycle	S1-031-00829-000	1	-	-
Transducer, Pressure	S1-031-01262-000	1	-	-
Transducer, Pressure	S1-031-01977-000	1	-	-

460-3-60 VOLTAGE CODE 4 = NOMENCLATURE 7TH POSITION

POSITION 7 = 4
POSITION 12 = A

Damper, Backdraft	S1-026-35540-000	1	-	-
Damper, Backdraft	S1-026-34680-000	-	1	1
Panel, Hood, Bottom	S1-073-16157-000	-	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1

POSITION 7 = 4
POSITION 12 = A (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Panel, Hood, Side	S1-073-16155-000	1	1	1
Panel, Hood, Top	S1-073-16154-000	-	1	1
Panel, Hood, Top	S1-073-21888-000	1	-	-

POSITION 7 = 4
POSITION 12 = B
POSITION 14 = D, E, F, G, H, I, J

Actuator	S1-025-33490-000	1	1	1
Ball Joint, TY, DC	S1-029-08786-000	1	2	2
Belt, V, B62, 63.8	S1-028-08781-000	2	2	2
Blower, 15 x 15, Single	S1-026-35579-000	1	-	-
Blower, Dual	S1-026-34671-000	-	1	1
Connector, 1/4"	S1-029-18438-000	1	2	2
Crankarm	S1-029-22116-000	1	1	1
Element, Heater, OL Furnas K67	S1-024-19631-000	3	3	3
Fuse, Dual, 35 Amp., 250V, 13 x 16 x 3	S1-025-15491-000	3	3	3
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	1	1	1
Motor, 7.5HP, 230/460V	S1-024-25078-700	1	1	1
Panel, Hood, Bottom	S1-073-16157-000	-	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1
Panel, Hood, Side	S1-073-16155-000	1	1	1
Panel, Hood, Top	S1-073-21888-000	1	-	-
Panel, Hood, Top	S1-073-16154-000	-	1	1
Pivot, Brass w/Set Screw	S1-029-18439-000	7	14	14
Sheave, 2B5V52 Bore	S1-028-13270-000	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1
Transducer, Pressure	S1-031-01262-000	1	1	1

POSITION 7 = 4
POSITION 12 = D
POSITION 14 = D, E, F, G, H, I, J

Actuator	S1-025-33490-000	-	1	1
Ball Joint, TY, DC	S1-029-08786-000	-	2	2
Belt, V, B62, 63.8	S1-028-08781-000	-	2	2
Blade, Damper	S1-073-21754-000	-	4	4
Blade, Damper	S1-073-21755-000	-	4	4
Blower, Dual	S1-026-34671-000	-	1	1
Connector, 1/4"	S1-029-18438-000	-	2	2
Crankarm	S1-029-22116-000	-	1	1
Element, Heater	S1-024-21055-000	-	3	3
Fuse, Dual, 35 Amp., 600V, 1 1/6X	S1-025-18540-000	-	3	3
Fuseholder, #24, 60 Amp., 600V, 3 Pole	S1-025-18285-000	-	1	1
Motor, 15HP, 230/460V	S1-024-25080-000	-	1	1
Panel, Actuator	S1-073-16158-000	-	1	1
Panel, Hood, Bottom	S1-073-16157-000	-	1	1
Panel, Hood, Side	S1-073-16155-000	-	1	1

POSITION 7 = 4
POSITION 12 = D
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Panel, Hood, Side	S1-073-16156-000	-	1	1
Panel, Hood, Top	S1-073-16154-000	-	1	1
Pivot, Brass w/Set Screw	S1-029-18439-000	-	14	14
Sheave, 2B5V66	S1-028-12071-700	-	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	-	1	1
Starter, Furnace, 30 Amp.	S1-024-27527-000	-	1	1
Transducer, Pressure	S1-031-01262-000	-	1	1

POSITION 7 = 4
POSITION 12 = E
POSITION 14 = D, E, F, G, H, I, J

Actuator	S1-025-33490-000	1	1	1
Ball Joint, TY, DC	S1-029-08786-000	1	1	1
Belt, V, B62, 63.8	S1-028-08781-000	2	2	2
Blade, Damper	S1-073-21754-000	2	2	2
Blade, Damper	S1-073-21755-000	2	2	2
Blower, 15 x 15, Single	S1-026-35579-000	1	1	1
Crankarm	S1-029-22116-000	1	1	1
Damper, Blockoff	S1-073-16160-000	1	1	1
Element, Heater	S1-024-19099-000	3	3	3
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Motor, Blower, 7.5HP, 230/460V, 213T, 1750 RPM Nom	S1-024-27525-000	1	1	1
Panel, Hood, Side	S1-073-16155-000	1	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1
Panel, Hood, Top	S1-073-21888-000	1	1	1
Sheave, 2B5V52 Bore	S1-028-13270-000	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1
Transducer, Pressure	S1-031-01262-000	1	1	1

POSITION 7 = 4
POSITION 12 = T
POSITION 14 = D, E, F, G, H, I, J

Blower, Dual	S1-026-34671-000	-	1	1
Damper, Backdraft	S1-026-34753-000	-	2	2
Panel, Hood, Bottom	S1-073-16157-000	-	1	1
Panel, Hood, Side	S1-073-16155-000	-	1	1
Panel, Hood, Side	S1-073-16156-000	-	1	1
Panel, Hood, Top	S1-073-16154-000	-	1	1
Timer, Anti-Short Cycle	S1-031-00829-000	-	1	1
Transducer, Pressure	S1-031-01262-000	-	1	1

POSITION 7 = 4
POSITION 12 = H
POSITION 14 = D, E, F, G, H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Base, Motor Mounting	S1-073-16085-000	-	1	1
Belt, V, B62, 63.8	S1-028-08781-000	-	2	2
Blower, Dual	S1-026-34671-000	-	1	1
Controller, VFD, 7.5HP, 460V	S1-024-34504-000	-	1	1
Damper, Backdraft	S1-026-34753-000	-	2	2
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	-	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	1	1
Motor, 7.5HP, 230/460V	S1-024-25078-700	-	1	1
Panel, Exhaust, Blower	S1-073-16165-000	-	1	1
Panel, Hood, Bottom	S1-073-16157-000	-	1	1
Panel, Hood, Side	S1-073-16156-000	-	1	1
Panel, Hood, Side	S1-073-16155-000	-	1	1
Panel, Hood, Top	S1-073-16154-000	-	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	-	1	1
Sheave, 2B5V52 Bore	S1-028-13270-000	-	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	-	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	-	1	1
Timer, Anti-Short Cycle	S1-031-00829-000	-	1	1
Transducer, Pressure	S1-031-01262-000	-	1	1
Transducer, Pressure	S1-031-01977-000	-	1	1

POSITION 7 = 4
POSITION 12 = K
POSITION 14 = D, E, F, G, H, I, J

Actuator	S1-025-33490-000	1	1	1
Ball Joint, TY, DC	S1-029-08786-000	1	1	1
Belt, V, B62, 63.8	S1-028-08781-000	2	2	2
Blower, 15 x 15, Single	S1-026-35579-000	1	1	1
Connector, 1/4"	S1-029-18438-000	1	1	1
Crankarm	S1-029-22116-000	1	1	1
Element, Heater	S1-024-19099-000	3	3	3
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Motor, Blower, 7.5HP, 230/460V, 213T, 1750 RPM Nom	S1-024-27525-000	1	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1
Panel, Hood, Top	S1-073-21888-000	1	1	1
Pivot, Brass w/Set Screw	S1-029-18439-000	7	7	7
Sheave, 2B5V52 Bore	S1-028-13270-000	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1
Transducer, Pressure	S1-031-01262-000	1	1	1

POSITION 7 = 4
POSITION 12 = T
POSITION 14 = D, E, F, G, H, I, J

Description	Part Number	Model		
		Y22	Y23	Y24
Belt, V, B62, 63.8	S1-028-08781-000	-	2	2
Blower, Dual	S1-026-34671-000	-	1	1
Controller, VFD, 10HP, 460V	S1-024-34505-000	-	1	1
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	-	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	-	1	1
Motor, Blower	S1-024-25079-000	-	1	1
Panel, Hood, Bottom	S1-073-16157-000	-	1	1
Panel, Hood, Side	S1-073-16156-000	-	1	1
Panel, Hood, Side	S1-073-16155-000	-	1	1
Panel, Hood, Top	S1-073-16154-000	-	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	-	1	1
Sheave, 2B5V60 Bore	S1-028-13271-000	-	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	-	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	-	1	1
Timer, Anti-Short Cycle	S1-031-00829-000	-	1	1
Transducer, Pressure	S1-031-01262-000	-	1	1
Transducer, Pressure	S1-031-01977-000	-	1	1

POSITION 7 = 4
POSITION 12 = V
POSITION 14 = D, E, F, G, H, I, J

Belt, V, B62, 63.8	S1-028-08781-000	2	2	2
Blower, 15 x 15, Single	S1-026-35579-000	1	1	1
Controller, VFD, 7.5HP, 460V	S1-024-34504-000	1	1	1
Damper, Backdraft	S1-026-34753-000	1	1	1
Fuse, Dual, 15 Amp., 600V, 13 x 16 x 5	S1-025-05741-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Motor, Blower, 7.5HP, 230/460V, 213T, 1750 RPM Nom	S1-024-27525-000	1	1	1
Panel, Hood, Side	S1-073-16155-000	1	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1
Panel, Hood, Top	S1-073-21888-000	1	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	1	1	1
Sheave, 2B5V52 Bore	S1-028-13270-000	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	1	1
Timer, Anti-Short Cycle	S1-031-00829-000	1	1	1
Transducer, Pressure	S1-031-01262-000	1	1	1
Transducers, Pressure	S1-031-01977-000	1	1	1

POSITION 7 = 4
POSITION 12 = W
POSITION 14 = D, E, F, G, H, I, J

Belt, V, B62, 63.8	S1-028-08781-000	2	2	2
Blower, 15 x 15, Single	S1-026-35579-000	1	-	-
Blower, Dual	S1-026-34671-000	-	1	1

POSITION 7 = 4
POSITION 12 = W
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Controller, VFD, 10HP, 460V	S1-024-34505-000	1	1	1
Fuse, Dual, 25 Amp., 600V, 13 x 16 x 5	S1-025-12805-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Motor, Blower, 10HP, 230/460V, D215T, 1800 Rpm	S1-024-26005-000	1	1	1
Panel, Hood, Bottom	S1-073-16157-000	-	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1
Panel, Hood, Side	S1-073-16155-000	1	1	1
Panel, Hood, Top	S1-073-16154-000	-	1	1
Panel, Hood, Top	S1-073-21888-000	1	-	-
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	1	1	1
Sheave, 2B5V60 Bore	S1-028-13271-000	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	1	1
Timer, Anti-Short Cycle	S1-031-00829-000	1	1	1
Transducer, Pressure	S1-031-01262-000	1	1	1
Transducer, Pressure	S1-031-01977-000	1	1	1

POSITION 7 = 4
POSITION 12 = X
POSITION 14 = D, E, F, G, H, I, J

Belt, V, B62, 63.8	S1-028-08781-000	2	2	2
Blower, Dual	S1-026-34671-000	1	1	1
Controller, VFD, 15HP, 460V	S1-024-34506-000	1	1	1
Damper, Backdraft	S1-026-34753-000	2	2	2
Fuse, Dual, 35 Amp., 600V, 1 1/6X	S1-025-18540-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Motor, 15HP, 230/460V	S1-024-27526-000	1	1	1
Panel, Hood, Bottom	S1-073-16157-000	1	1	1
Panel, Hood, Side	S1-073-16155-000	1	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1
Panel, Hood, Top	S1-073-16154-000	1	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	1	1	1
Sheave, 2B5V66 Bore	S1-028-12071-700	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	1	1
Timer, Anti-Short Cycle	S1-031-00829-000	1	1	1
Transducer, Pressure	S1-031-01262-000	1	1	1
Transducer, Pressure	S1-031-01977-000	1	1	1

POSITION 7 = 2
POSITION 12 = B
POSITION 14 = D, E, F, G, H, I, J

Actuator	S1-025-33490-000	1	1	1
Ball Joint, TY, DC	S1-029-08786-000	2	2	2
Belt, V, B62, 63.8	S1-028-08781-000	2	2	2

POSITION 7 = 2
POSITION 12 = B
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Blower, Dual	S1-026-34671-000	1	1	1
Crankarm	S1-029-22116-000	1	1	1
Element, Heater, OL Furnas K67	S1-024-19631-000	3	3	3
Fuse, Dual, 35 Amp., 250V, 13 x 16 x 3	S1-025-15491-000	3	3	3
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	1	1	1
Motor, 7.5HP, 230/460V	S1-024-25078-700	1	1	1
Panel, Actuator	S1-073-16158-000	1	1	1
Panel, Hood, Bottom	S1-073-16157-000	1	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1
Panel, Hood, Side	S1-073-16155-000	1	1	1
Panel, Hood, Top	S1-073-16154-000	1	1	1
Sheave, 2B5V52 Bore	S1-028-13270-000	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1
Transducer, Pressure	S1-031-01262-000	1	1	1

POSITION 7 = 2
POSITION 12 = D
POSITION 14 = D, E, F, G, H, I, J

Actuator	S1-025-33490-000	-	-	1
Ball Joint, TY, DC	S1-029-08786-000	-	-	2
Belt, V, B62, 63.8	S1-028-08781-000	-	-	2
Blower, Dual	S1-026-34671-000	-	-	1
Crankarm	S1-029-22116-000	-	-	1
Element, Heater, OL Furnas K74	S1-024-25343-700	-	-	3
Fuse, Dual, 70 Amp., 250V, 3/4X	S1-025-18539-000	-	-	3
Fuseholder, #5, 100 Amp., 250V, 3 Pole	S1-025-26395-000	-	-	1
Motor, 15HP, 230/460V	S1-024-25080-000	-	-	1
Panel, Hood, Bottom	S1-073-16157-000	-	-	1
Panel, Hood, Side	S1-073-16156-000	-	-	1
Panel, Hood, Side	S1-073-16155-000	-	-	1
Panel, Hood, Top	S1-073-16154-000	-	-	1
Sheave, 2B5V66 Bore	S1-028-12071-700	-	-	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	-	-	1
Starter, Furnace, 50 Amp.	S1-024-27529-000	-	-	1
Transducer, Pressure	S1-031-01262-000	-	-	1

POSITION 7 = 2
POSITION 12 = V
POSITION 14 = D, E, F, G, H, I, J

Belt, V, B62, 63.8	S1-028-08781-000	-	2	2
Blower, Dual	S1-026-34671-000	-	1	1
Controller, VFD, 7.5HP, 208/230V	S1-024-34512-000	-	1	1
Fuse, Dual, 35 Amp., 250V	S1-025-15491-000	-	3	3
Fuseholder, #20, 60 Amp., 250V, 3 Pole	S1-025-18283-000	-	1	1

POSITION 7 = 2
POSITION 12 = V
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Motor, Blower, 7.5HP, 230/460V, 213T, 1750 RPM Nom	S1-024-27525-000	-	1	1
Panel, Hood, Bottom	S1-073-16157-000	-	1	1
Panel, Hood, Side	S1-073-16155-000	-	1	1
Panel, Hood, Side	S1-073-16156-000	-	1	1
Panel, Hood, Top	S1-073-16154-000	-	1	1
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	-	1	1
Sheave, 2B5V52 Bore	S1-028-13270-000	-	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	-	1	1
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	-	1	1
Timer, Anti-Short Cycle	S1-031-00829-000	-	1	1
Transducer, Pressure	S1-031-01262-000	-	1	1
Transducer, Pressure	S1-031-01977-000	-	1	1

POSITION 7 = 2
POSITION 12 = Y
POSITION 14 = D, E, F, G, H, I, J

Belt, V, B62, 63.8	S1-028-08781-000	2	-	-
Blower, 15 x 15, Single	S1-026-35579-000	1	-	-
Controller, VFD, 5HP, 460V	S1-024-34502-000	1	-	-
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	3	-	-
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	-	-
Motor, 5HP, 230/460V	S1-024-27591-001	1	-	-
Panel, Hood, Side	S1-073-16155-000	1	-	-
Panel, Hood, Side	S1-073-16156-000	1	-	-
Panel, Hood, Top	S1-073-21888-000	1	-	-
Relay, Control, 24V, 50/60 Hz, DPDT	S1-024-27542-000	1	-	-
Sheave, 2 Groove, 2B5V46	S1-028-13358-000	1	-	-
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	-	-
Terminal Block, 2 Pole, 15 Amp., 150V	S1-025-32770-000	1	-	-
Timer, Anti-Short Cycle	S1-031-00829-000	1	-	-
Transducer, Pressure	S1-031-01262-000	1	-	-
Transducer, Pressure	S1-031-01977-000	1	-	-

575-3-60 VOLTAGE CODE 5 = NOMENCLATURE 7TH POSITION

POSITION 7 = 5
POSITION 12 = C
POSITION 14 = D, E, F, G, H, I, J

Actuator	S1-025-33490-000	1	1	1
Ball Joint, TY, DC	S1-029-08786-000	1	1	1
Belt, V, B62, 63.8	S1-028-08781-000	2	2	2
Blower, 15 x 15, Single	S1-026-35579-000	1	1	1
Crankarm	S1-029-22116-000	1	1	1
Fuse, Dual, 20 Amp., 600V, 13 x 16 x 5	S1-025-12804-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Motor, 10HP	S1-024-27559-000	1	1	1

POSITION 7 = 5
POSITION 12 = C
POSITION 14 = D, E, F, G, H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Overload	S1-024-26052-000	3	3	3
Panel, Hood, Side	S1-073-16155-000	1	1	1
Panel, Hood, Side	S1-073-16156-000	1	1	1
Panel, Hood, Top	S1-073-21888-000	1	1	1
Sheave, 2B5V60 Bore	S1-028-13271-000	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1
Transducer, Duct Pressure	S1-031-01262-000	1	1	1

POSITION 7 = 5
POSITION 12 = E
POSITION 14 = D, E, F, G, H, I, J

Starter Element	S1-024-19415-000	3	3	3
Actuator	S1-025-33490-000	1	1	1
Ball Joint, TY, DC	S1-029-08786-000	1	2	2
Belt, V, B62, 63.8	S1-028-08781-000	2	2	2
Blower, 15 x 15, Single	S1-026-35579-000	1	-	-
Blower, Dual	S1-026-34671-000	-	1	1
Crankarm	S1-029-22116-000	1	1	1
Fuse, Dual, 12 Amp., 600V, 13 x 16 x 5	S1-025-06079-000	3	3	3
Fuseholder, #23, 30 Amp., 600V, 3 Pole	S1-025-18284-000	1	1	1
Motor, 7.5HP, 575V	S1-024-26060-000	1	1	1
Pivot, Brass w/Set Screw	S1-029-18439-000	7	14	14
Sheave, 2B5V52 Bore	S1-028-13270-000	1	1	1
Sheave, Fixed, 2 Groove, Bore	S1-028-13274-000	1	1	1
Starter, Furnace, 30 Amp.	S1-024-27527-000	1	1	1
Transducer, Pressure	S1-031-01262-000	1	1	1

HEAT (Beginning Reference - Positions 5 and 6 in Unit Model)
ELECTRIC HEAT

POSITIONS 5 & 6 = E1
POSITION 7 = 4
POSITION 14 = H, I, J

Bracket, Door Latch	S1-073-19224-000	-	2	-
Bracket, Latch	S1-073-19226-000	-	2	-
Control, Limit, Backup	S1-025-32779-000	-	6	-
Control, Limit, Primary	S1-025-32774-000	-	1	-
Heat, Electric, 480V, 108kW	S1-025-32648-108	-	1	-
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	2	-
Plate, Door Latch	S1-073-19225-000	-	2	-
Tongue, Door Latch	S1-029-22121-000	-	2	-

POSITIONS 5 & 6 = E4
POSITION 7 = 4
POSITION 14 = D, E, F, G

Description	Part Number	Model		
		Y22	Y23	Y24
Bracket, Door Latch	S1-073-19224-000	2	2	-
Bracket, Latch	S1-073-19226-000	2	2	-
Control, Limit, Backup	S1-025-32776-000	2	2	-
Control, Limit, Primary	S1-025-32773-000	1	1	-
Heat, Electric, 480V, 40kW	S1-025-32648-040	1	1	-
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	2	2	-
Plate, Door Latch	S1-073-19225-000	2	2	-
Tongue, Door Latch	S1-029-22121-000	2	2	-

POSITIONS 5 & 6 = E4
POSITION 7 = 5
POSITION 14 = H, I, J

Bracket, Door Latch	S1-073-19224-000	-	2	-
Bracket, Latch	S1-073-19226-000	-	2	-
Control, Limit, Backup	S1-025-32775-000	-	2	-
Control, Limit, Primary	S1-025-32773-000	-	1	-
Heat, Electric, 575V, 40kW	S1-025-32649-040	-	1	-
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	2	-
Plate, Door Latch	S1-073-19225-000	-	2	-
Tongue, Door Latch	S1-029-22121-000	-	2	-

POSITIONS 5 & 6 = E8
POSITION 7 = 4
POSITION 14 = H, I, J

Bracket, Door Latch	S1-073-19224-000	-	-	2
Bracket, Latch	S1-073-19226-000	-	-	2
Control, Limit, Backup	S1-025-32778-000	-	-	4
Control, Limit, Primary	S1-025-32773-000	-	-	1
Heat, Electric, 480V, 80kW	S1-025-32648-080	-	-	1
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	-	2
Plate, Door Latch	S1-073-19225-000	-	-	2
Tongue, Door Latch	S1-029-22121-000	-	-	2

GAS HEAT

POSITIONS 5 & 6 = N4
POSITION 7 = 5
POSITION 14 = H, I, J

Pressure, Tap	S1-023-16881-000	2	-	-
Switch, Pressure	S1-024-25975-000	2	-	-
Blower Assy., Vent 230-1-60V	S1-024-34546-000	2	-	-
Switch, Rollout, 160	S1-025-27747-003	2	-	-
Ignitor	S1-025-32661-001	2	-	-
Sensor, Flame	S1-025-32661-002	2	-	-
Valve, Gas	S1-025-32695-000	2	-	-
Switch, Limit, 150	S1-025-32706-000	2	-	-
Gasket, High Temperature	S1-028-11648-000	4	-	-
Gasket, Ventor	S1-028-14847-000	2	-	-
Orifice, Gas, Burner, #30	S1-029-20423-030	10	-	-

POSITIONS 5 & 6 = N4
POSITION 7 = 5
POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Manifold, Gas	S1-029-21176-000	2	-	-
Manifold, Gas Inlet	S1-029-22102-000	1	-	-
Burner, Gas	S1-029-22115-000	10	-	-
Tongue, Door Latch	S1-029-22121-000	2	-	-
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	2	-	-
Bracket, Rollout Switch	S1-073-17161-000	2	-	-
Bracket, Door Latch	S1-073-19224-000	2	-	-
Plate, Door Latch	S1-073-19225-000	2	-	-
Bracket, Latch	S1-073-19226-000	2	-	-
Heat Exchanger	S1-373-16198-001	2	-	-
Door, Heat Section	S1-373-16198-035	1	-	-
Ignition, Mod, Integrated	S1-031-01283-000	2	-	-
Cable, Ignition	S1-025-32696-000	2	-	-
Fuse, 2.5 Amp., 600V, Class CC	S1-025-32729-001	2	-	-
Fuse, Dual, 3 Amp., 250V, 1/4X	S1-025-21113-000	2	-	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	-	-
Fuseholder, #2, 15 Amp., 250V, 1 Pole	S1-025-13991-000	2	-	-
Terminal Block, 6P, 300	S1-025-20701-000	1	-	-
Transformer, .50KVA, 600 PRI	S1-025-30886-000	1	-	-

POSITIONS 5 & 6 = N2
POSITION 7 = 4
POSITION 14 = H, I, J

Pressure, Tap	S1-023-16881-000	-	1	1
Switch, Pressure	S1-024-25975-000	-	1	1
Blower Assy., Vent 230-1-60V	S1-024-34546-000	-	1	1
Switch, Rollout, 160	S1-025-27747-003	-	1	1
Ignitor	S1-025-32661-001	-	1	1
Sensor, Flame	S1-025-32661-002	-	1	1
Valve, Gas	S1-025-32695-000	-	1	1
Switch, Limit, 150	S1-025-32706-000	-	1	1
Gasket, High Temperature	S1-028-11648-000	-	2	2
Gasket, Ventor	S1-028-14847-000	-	1	1
Orifice, Gas, Burner, #30	S1-029-20423-030	-	5	5
Manifold, Gas	S1-029-21176-000	-	1	1
Burner, Gas	S1-029-22115-000	-	5	5
Tongue, Door Latch	S1-029-22121-000	-	2	2
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	2	2
Bracket, Tube Exchanger	S1-073-16053-000	-	2	2
Baffle, Tube Heat	S1-073-16178-000	-	5	5
Heat Exchanger	S1-373-16198-001	-	5	5
Bracket, Door Latch	S1-073-19224-000	-	2	2
Plate, Door Latch	S1-073-19225-000	-	2	2
Bracket, Latch	S1-073-19226-000	-	2	2
Cable, Ignition	S1-025-32696-000	-	1	1
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	-	2	2
Fuse, Dual, 3 Amp., 250V, 1/4X	S1-025-21113-000	-	2	2

POSITIONS 5 & 6 = N2

POSITION 7 = 4

POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	2	2
Fuseholder, #2, 15 Amp., 250V, 1 Pole	S1-025-13991-000	-	2	2
Ignition, Mod, Integrated	S1-031-01283-000	-	1	1
Transformer, .50KVA, 240/480V	S1-025-26309-000	-	1	1

POSITIONS 5 & 6 = S2

POSITION 7 = 4

POSITION 14 = D, E, F, G

Pressure, Tap	S1-023-16881-000	-	1	-
Switch, Pressure	S1-024-25975-000	-	1	-
Blower Assy., Vent 230-1-60V	S1-024-34546-000	-	1	-
Switch, Rollout, 160	S1-025-27747-003	-	1	-
Ignitor	S1-025-32661-001	-	1	-
Sensor, Flame	S1-025-32661-002	-	1	-
Valve, Gas	S1-025-32695-000	-	1	-
Switch, Limit, 150	S1-025-32706-000	-	1	-
Heat Exchanger, SST, 5 Tube	S1-373-27158-001	-	1	-
Gasket, Ventor	S1-028-14847-000	-	1	-
Orifice, Gas, Burner, #30	S1-029-20423-030	-	5	-
Manifold, Gas	S1-029-21176-000	-	1	-
Burner, Gas	S1-029-22115-000	-	5	-
Tongue, Door Latch	S1-029-22121-000	-	2	-
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	2	-
Bracket, Tube Exchanger	S1-073-16053-000	-	2	-
Baffle, Tube Heat	S1-073-16178-000	-	5	-
Bracket, Rollout Switch	S1-073-17161-000	-	1	-
Bracket, Door Latch	S1-073-19224-000	-	2	-
Plate, Door Latch	S1-073-19225-000	-	2	-
Bracket, Latch	S1-073-19226-000	-	2	-
Cable, Ignition	S1-025-32696-000	-	1	-
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	-	2	-
Fuse, Dual, 3 Amp., 250V, 1/4X	S1-025-21113-000	-	2	-
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	2	-
Fuseholder, #2, 15 Amp., 250V, 1 Pole	S1-025-13991-000	-	2	-
Ignition, Mod, Integrated	S1-031-01283-000	-	1	-
Transformer, .50KVA, 240/480V	S1-025-26309-000	-	1	-

POSITIONS 5 & 6 = N4

POSITION 7 = 4

POSITION 14 = H, I, J

Pressure, Tap	S1-023-16881-000	-	2	2
Switch, Pressure	S1-024-25975-000	-	2	2
Blower Assy., Vent 230-1-60V	S1-024-34546-000	-	2	2
Switch, Rollout, 160	S1-025-27747-003	-	2	2
Ignitor	S1-025-32661-001	-	2	2
Sensor, Flame	S1-025-32661-002	-	2	2

POSITIONS 5 & 6 = N4
POSITION 7 = 4
POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Valve, Gas	S1-025-32695-000	-	2	2
Switch, Limit, 185	S1-025-32700-000	-	2	2
Gasket, High Temperature	S1-028-11648-000	-	4	4
Gasket, Ventor	S1-028-14847-000	-	2	2
Orifice, Gas, Burner, #30	S1-029-20423-030	-	10	10
Manifold, Gas	S1-029-21176-000	-	2	2
Manifold, Gas Inlet	S1-029-22102-000	-	1	1
Burner, Gas	S1-029-22115-000	-	10	10
Tongue, Door Latch	S1-029-22121-000	-	2	2
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	2	2
Bracket, Tube Exchanger	S1-073-16053-000	-	4	4
Baffle, Tube Heat	S1-073-16178-000	-	10	10
Bracket, Rollout Switch	S1-073-17161-000	-	2	2
Bracket, Door Latch	S1-073-19224-000	-	2	2
Plate, Door Latch	S1-073-19225-000	-	2	2
Bracket, Latch	S1-073-19226-000	-	2	2
Heat Exchanger	S1-373-16198-001	-	2	2
Cable, Ignition	S1-025-32696-000	-	2	2
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	-	2	2
Fuse, Dual, 3 Amp., 250V, 1/4X	S1-025-21113-000	-	2	2
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	2	2
Fuseholder, #2, 15 Amp., 250V, 1 Pole	S1-025-13991-000	-	2	2
Ignition, Mod, Integrated	S1-031-01283-000	-	2	2
Terminal Block, 6P, 300	S1-025-20701-000	-	1	1
Transformer, .50KVA, 240/480V	S1-025-26309-000	-	1	1

POSITIONS 5 & 6 = N4
POSITION 7 = 2
POSITION 14 = H, I, J

Pressure, Tap	S1-023-16881-000	-	-	2
Switch, Pressure	S1-024-25975-000	-	-	2
Blower Assy., Vent 230-1-60V	S1-024-34546-000	-	-	2
Strap, Cable 13.0 Bdl UV	S1-025-27531-000	-	-	2
Strap, Cable 1.75 Bdl UV	S1-025-27642-000	-	-	20
Switch, Rollout, 160	S1-025-27747-003	-	-	2
Ignitor	S1-025-32661-001	-	-	2
Sensor, Flame	S1-025-32661-002	-	-	2
Valve, Gas	S1-025-32695-000	-	-	2
Switch, Limit, 185	S1-025-32700-000	-	-	2
Gasket, High Temperature	S1-028-11648-000	-	-	4
Gasket, Ventor	S1-028-14847-000	-	-	2
Orifice, Gas, Burner, #30	S1-029-20423-030	-	-	10
Manifold, Gas	S1-029-21176-000	-	-	2
Manifold, Gas Inlet	S1-029-22102-000	-	-	1
Burner, Gas	S1-029-22115-000	-	-	10
Tongue, Door Latch	S1-029-22121-000	-	-	2
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	-	2

POSITIONS 5 & 6 = N4
POSITION 7 = 2
POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Bracket, Tube Exchanger	S1-073-16053-000	-	-	4
Baffle, Tube Heat	S1-073-16178-000	-	-	10
Bracket, Rollout Switch	S1-073-17161-000	-	-	2
Bracket, Door Latch	S1-073-19224-000	-	-	2
Plate, Door Latch	S1-073-19225-000	-	-	2
Bracket, Latch	S1-073-19226-000	-	-	2
Heat Exchanger	S1-373-16198-001	-	-	1
Terminal Block, 6P, 300	S1-025-20701-000	-	-	1
Cable, Ignition	S1-025-32696-000	-	-	2
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	-	-	2
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	-	2
Ignition, Mod, Integrated	S1-031-01283-000	-	-	2

POSITIONS 5 & 6 = N7
POSITION 7 = 2
POSITION 14 = D, E, F, G

Pressure, Tap	S1-023-16881-000	-	-	3
Switch, Pressure	S1-024-25975-000	-	-	3
Blower Assy., Vent 230-1-60V	S1-024-34546-000	-	-	3
Strap, Cable 13.0 Bdl UV	S1-025-27531-000	-	-	2
Strap, Cable 1.75 Bdl UV	S1-025-27642-000	-	-	30
Switch, Rollout, 160	S1-025-27747-003	-	-	3
Ignitor	S1-025-32661-001	-	-	3
Sensor, Flame	S1-025-32661-002	-	-	3
Valve, Gas	S1-025-32695-000	-	-	3
Switch, Limit, 160	S1-025-33333-000	-	-	3
Gasket, High Temperature	S1-028-11648-000	-	-	6
Gasket, Ventor	S1-028-14847-000	-	-	3
Orifice, Gas, Burner, #30	S1-029-20423-030	-	-	15
Manifold, Gas	S1-029-21176-000	-	-	3
Burner, Gas	S1-029-22115-000	-	-	15
Tongue, Door Latch	S1-029-22121-000	-	-	2
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	-	2
Bracket, Tube Exchanger	S1-073-16053-000	-	-	6
Baffle, Tube Heat	S1-073-16178-000	-	-	15
Bracket, Rollout Switch	S1-073-17161-000	-	-	3
Bracket, Door Latch	S1-073-19224-000	-	-	2
Plate, Door Latch	S1-073-19225-000	-	-	2
Bracket, Latch	S1-073-19226-000	-	-	2
Heat Exchanger	S1-373-16198-001	-	-	3
Cable, Ignition	S1-025-32696-000	-	-	2
Cable, Ignition, 44"	S1-025-33352-000	-	-	1
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	-	-	2
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	-	2
Ignition, Mod, Integrated	S1-031-01283-000	-	-	3
Terminal Block, 6P, 300	S1-025-20701-000	-	-	1

POSITIONS 5 & 6 = N7

POSITION 7 = 4

POSITION 14 = A, B, C

Description	Part Number	Model		
		Y22	Y23	Y24
Pressure, Tap	S1-023-16881-000	-	-	3
Switch, Pressure	S1-024-25975-000	-	-	3
Blower Assy., Vent 230-1-60V	S1-024-34546-000	-	-	3
Switch, Rollout, 160	S1-025-27747-003	-	-	3
Ignitor	S1-025-32661-001	-	-	3
Sensor, Flame	S1-025-32661-002	-	-	3
Valve, Gas	S1-025-32695-000	-	-	3
Switch, Limit, 160	S1-025-33333-000	-	-	3
Gasket, High Temperature	S1-028-11648-000	-	-	6
Gasket, Vantor	S1-028-14847-000	-	-	3
Orifice, Gas, Burner, #30	S1-029-20423-030	-	-	15
Manifold, Gas	S1-029-21176-000	-	-	3
Burner, Gas	S1-029-22115-000	-	-	15
Tongue, Door Latch	S1-029-22121-000	-	-	2
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	-	2
Bracket, Tube Exchanger	S1-073-16053-000	-	-	6
Baffle, Tube Heat	S1-073-16178-000	-	-	15
Bracket, Rollout Switch	S1-073-17161-000	-	-	3
Bracket, Door Latch	S1-073-19224-000	-	-	2
Plate, Door Latch	S1-073-19225-000	-	-	2
Bracket, Latch	S1-073-19226-000	-	-	2
Heat Exchanger	S1-373-16198-001	-	-	3
Cable, Ignition	S1-025-32696-000	-	-	2
Cable, Ignition, 44"	S1-025-33352-000	-	-	1
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	-	-	2
Fuse, Dual, 3 Amp., 250V, 1/4X	S1-025-21113-000	-	-	2
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	-	2
Fuseholder, #2, 15 Amp., 250V, 1 Pole	S1-025-13991-000	-	-	2
Ignition, Mod, Integrated	S1-031-01283-000	-	-	3
Relay, Control, 24V, 50/60 Hz, SPDT	S1-024-24116-000	-	-	3
Terminal Block, 6P, 300	S1-025-20701-000	-	-	1
Transformer, .50KVA, 240/480V	S1-025-26309-000	-	-	1

POSITIONS 5 & 6 = N7

POSITION 7 = 4

POSITION 14 = H, I, J

Pressure, Tap	S1-023-16881-000	-	-	3
Switch, Pressure	S1-024-25975-000	-	-	3
Blower Assy., Vent 230-1-60V	S1-024-34546-000	-	-	3
Switch, Rollout, 160	S1-025-27747-003	-	-	3
Ignitor	S1-025-32661-001	-	-	3
Sensor, Flame	S1-025-32661-002	-	-	3
Valve, Gas	S1-025-32695-000	-	-	3
Switch, Limit, 160	S1-025-33333-000	-	-	3
Gasket, High Temperature	S1-028-11648-000	-	-	6
Gasket, Vantor	S1-028-14847-000	-	-	3
Orifice, Gas, Burner, #30	S1-029-20423-030	-	-	15

POSITIONS 5 & 6 = N7

POSITION 7 = 4

POSITION 14 = H, I, J (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Manifold, Gas	S1-029-21176-000	-	-	3
Burner, Gas	S1-029-22115-000	-	-	15
Tongue, Door Latch	S1-029-22121-000	-	-	2
Knob, Plastic, Fluted, 1/4-20	S1-029-22122-000	-	-	2
Bracket, Tube Exchanger	S1-073-16053-000	-	-	6
Baffle, Tube Heat	S1-073-16178-000	-	-	15
Bracket, Rollout Switch	S1-073-17161-000	-	-	3
Bracket, Door Latch	S1-073-19224-000	-	-	2
Plate, Door Latch	S1-073-19225-000	-	-	2
Bracket, Latch	S1-073-19226-000	-	-	2
Heat Exchanger	S1-373-16198-001	-	-	3
Cable, Ignition	S1-025-32696-000	-	-	2
Cable, Ignition, 44"	S1-025-33352-000	-	-	1
Fuse, 3 Amp., 600V, Class CC	S1-025-32730-001	-	-	2
Fuse, Dual, 3 Amp., 250V, 1/4X	S1-025-21113-000	-	-	2
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	-	-	2
Fuseholder, #2, 15 Amp., 250V, 1 Pole	S1-025-13991-000	-	-	2
Ignition, Mod, Integrated	S1-031-01283-000	-	-	3
Terminal Block, 6P, 300	S1-025-20701-000	-	-	1
Transformer, .50KVA, 240/480V	S1-025-26309-000	-	-	1

HOT WATER COIL (Beginning Reference - Positions 5 and 6 in Unit Model)

1 ROW

POSITIONS 5 & 6 = W1

Coil, Hot Water 1 Row	S1-026-35522-001	1	-	-
Panel, Blockoff Top	S1-073-21591-000	1	-	-
Angle, Support, Side	S1-073-21595-000	2	-	-
Liner, Blockoff Front	S1-073-21641-000	1	-	-
Panel, Support, HWC	S1-073-21645-000	1	-	-
Panel, Support, Front	S1-073-21646-000	1	-	-
Liner, Support, Front	S1-073-21649-000	1	-	-

2 ROW

POSITIONS 5 & 6 = W2

Coil, Hot Water 2 Row	S1-026-35522-002	1	-	1
Panel, Blockoff Top	S1-073-21591-000	1	-	1
Angle, Support, Side	S1-073-21595-000	2	-	2
Liner, Blockoff Front	S1-073-21641-000	1	-	1
Panel, Support, HWC	S1-073-21645-000	1	-	1
Panel, Support, Front	S1-073-21646-000	1	-	1
Liner, Support, Front	S1-073-21649-000	1	-	1

STEAM HEAT

Coil, Steam Coil 1 Row	S1-026-35522-003	1	1	1
Plate, Gas Blockoff	S1-073-17143-000	2	2	2
Panel, Blockoff Top	S1-073-21591-000	1	1	1
Panel, Support, Rear	S1-073-21594-000	1	1	1

STEAM HEAT (CONTINUED)

Description	Part Number	Model		
		Y22	Y23	Y24
Angle, Support, Side	S1-073-21595-000	2	2	2
Panel, Support, Steam Coil	S1-073-21639-000	1	1	1
Liner, Blockoff Front	S1-073-21641-000	1	1	1
Liner, Blockoff Front	S1-073-21642-000	2	2	2
Angle, Steam Coil Blockoff	S1-073-21773-000	2	2	2

FILTER OPTION (Beginning Reference - Position 11 in Unit Model)**POSITION 11 = A**

Filter, Air Trowa 2 x 20 x 25	S1-026-01730-000	6	6	6
Filter, Air 2 x 16 x 25	S1-026-03616-000	4	4	4

POSITION 11 = B

Filter, Air Trowa 2 x 20 x 25	S1-026-01730-000	6	6	6
Filter, Air 2 x 16 x 25	S1-026-03616-000	4	4	4
Filter, 16 x 25, 6", 65%	S1-026-34681-000	4	4	4
Filter, 20 x 25, 6", 65%	S1-026-34685-000	6	6	6

POSITION 11 = C

Filter, Air Trowa, 2 x 20 x 25	S1-026-01730-000	6	6	6
Filter, Air 2 x 16 x 25	S1-026-03616-000	4	4	4
Filter, 16 x 25, 6", 95%	S1-026-34682-000	4	4	4
Filter, 20 x 25, 6", 95%	S1-026-34686-000	6	6	6

POSITION 11 = D

Filter, Air Trowa Pleated	S1-026-32091-000	6	6	6
Filter, 16 x 25, 2"	S1-026-34575-000	4	4	4

DISCONNECT OPTION (Beginning Reference - Position 14 in Unit Model)**POSITION 14 = A, D, H**

Plate, Gas Blockoff	S1-073-17143-000	1	1	1
Guard, Power Switch	S1-073-18725-000	1	1	1
Plate, Patch Disconnect	S1-073-26017-000	1	1	1

POSITION 14 = E

Switch, Disconnect, 400 Amp., 600V	S1-025-32678-000	1	1	1
Guard, Power Switch	S1-073-18725-000	1	1	1
Plate, Disc Cover, 400 Amp.	S1-073-26008-000	1	1	1

POSITION 14 = F, G, I, J

Guard, Power Switch	S1-073-18725-000	1	1	1
Switch, Disconnect, 250 Amp., 600V	S1-025-32677-000	1	1	1
Plate, Disc Cover, 250 Amp.	S1-073-26007-000	1	1	1

CONVENIENCE OUTLET (Beginning Reference - Position 14 in Unit Model)**POSITION 14 = A, C, D, F, H, J**

Plate, Gas Blockoff	S1-073-17143-000	1	1	1
Plate, Outlet Cover	S1-073-18721-000	1	1	1

POSITION 14 = B, E, G, I
POSITION 7 = 2

Description	Part Number	Model		
		Y22	Y23	Y24
Circuit Breaker, 1 Pole, 20 Amp., 250V	S1-024-27517-000	1	1	1
Cover, Switch, Plastic	S1-025-32675-000	1	1	1
Fuse, Time Delay, 30 Amp., 600V, Class CC	S1-025-32733-001	2	2	2
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Outlet, Convenience, 20 Amp., 125V	S1-025-31987-000	1	1	1
Transformer, 3KVA, 208/230-120V	S1-025-32672-240	1	1	1

POSITION 14 = B, E, G, I
POSITION 7 = 4

Circuit Breaker, 1 Pole, 20 Amp., 250V	S1-024-27517-000	1	1	1
Cover, Switch, Plastic	S1-025-32675-000	1	1	1
Fuse, 15 Amp., 600V	S1-025-32732-001	2	2	2
Fuseholder, #1, 30 Amp., 600V Max., 1 Pole	S1-025-17407-000	2	2	2
Outlet, Convenience, 20 Amp., 125V	S1-025-31987-000	1	1	1
Transformer, 3KVA, 240/480-120/240V	S1-025-32762-000	1	1	1

